



FPS DX-S Instruction, Operating, & Maintenance Manual

COMPACT FUEL MAINTENANCE SYSTEM

REV0302DXS010120




Table of Contents

Table of Contents	2
General Overview	3
FPS DX-S Specifications	3
System Components	4
Control and Safety Devices	4
Pump/Motor	4
Strainer	4
Fuel Conditioner	4
Fine Filter	4
Plumbing	4
System Operation	5
Pump Operation	5
Alarms	5
Primary Inspection	6
Checklist	6
Installation	7
Mounting	7
Electrical	7
Plumbing	7
Typical Plumbing Installation (Schematically)	8
Important Installation Precautions	8
Controller	9
Setting the Current Date and Time	9
Programming the Timer	9
Priming the System	10
Priming Procedure	10
Commissioning/Initial Start-Up	11
Gauge Venting	11
Switch Adjustments	11
Initial Test Procedures	11
Maintenance	12
Preventative Maintenance	12
Servicing the Fine Filter	12
Replacement Filter Chart	13
Troubleshooting	14
Symptom Troubleshooting Guide	14
AXI International Limited Warranty	15
Warranty Claim Procedure	16
Technical Assistance and Ordering	17
Replacement Filter Elements	17
FPS DX-S System Identification	17

General Overview

FPS DX-S Specifications

Flow Rate.....	1.3 GPM/80 GPH (5 LPM/302.8 LPH) 640 gallons (2,423liters) per 8-hour shift 1,920 gallons (7,268 liters) per 24 hours
Primary Filter.....	10µ Particulate Fine Filter or 3µ Water Block
Strainer.....	50 Mesh Basket Strainer
Fuel Conditioner.....	LG-X 500 Inline Magnetic Conditioner
Plumbing.....	Stainless Steel
Inlet Port.....	1/2" Hose Barb
Outlet Port.....	1/2" Hose Barb
System Back Plate.....	Powder Coated Aluminum
Operating Temperature.....	41 - 104°F (5 - 40°C)
Electrical.....	12VDC/10A or 24VDC/5A
Pump.....	DC Gear Pump
Suction Capability (Primed).....	10 ft. (304.8 cm) Total Dynamic Head
Timer.....	Programmable Digital Timer
Maximum Fluid Viscosity.....	5 cSt
Outline Dimensions.....	≈ 15" x 18.5" x 7.5" (38 x 47 x 19 cm) (H x W x D)
Weight.....	≈ 20lbs. (9.1kg)

!WARNING! This system is not meant for use with gasoline or any other flammable liquids having a flash point less than 100°F (37.8° C). Use with gasoline or any flammable liquids at a temperature exceeding their flash point presents an immediate explosion and fire hazard.



System Components

Control and Safety Devices

- System Controller
 - Programmable Digital Timer
 - Memory retention during power outages
 - Alarm Indicator Light(s)
 - Breaker (Power On/Off switch)
- Pressure Switch
- Leak Detection Float Switch

Pump/Motor

- DC Gear Pump

Strainer

- 50 Mesh Basket Strainer

Fuel Conditioner

- Inline Magnetic Fuel Conditioner

Fine Filter

- Standard-issue 3 μ fine filter cartridge (other filter elements available)

Plumbing

- Stainless Steel



System Operation

Apply control power to unit. Place breaker for the System Controller in the “ON” position.

Pump Operation

Automatic Mode:

Press the ‘MANUAL’ button on the System Controller until ‘AUTO’ is indicated on the display. When the timer contacts close, the pump will start and run until the scheduled timer setting has expired. See the *Controller* section for setting the timer for scheduled run times.

On Mode:

Press the ‘MANUAL’ button on the System Controller until ‘ON’ is indicated on the display. The pump motor will run until the system is switched off, into “Auto” mode, or an alarm has been tripped.

Alarms

Alarms featured on the system include:

- Leak Detection (system shutdown, alarm indication)
 - Activated when the Float Switch in the system’s drip tray detects a raised liquid level. The system will go into an alarm state and the pump will not be allowed to be run until the alarm is addressed and cleared.

Note: Disposal of fuel and associated waste should be done in accordance with Federal, State and Local regulations.

- High Pressure (system shutdown, alarm indication)
 - Activated when the Pressure Switch, placed on the pressure side of the pump set, detects a reading above the factory set point (15 PSI). The system will go into an alarm state and the pump will not be allowed to run until the alarm is addressed and reset.

Once triggered alarms are addressed, each alarm can be reset via the System Controller.



Primary Inspection

Upon arrival, the system and accessories must be visually inspected before installation. Improper handling during shipping may cause physical or electrical problems. Immediately report or note any damages to the shipper.

Checklist

- ☐ If the packing crate shows signs of damage inspect the system for damage.
- ☐ Check the entire system for damage that could indicate internal mechanical or electrical problems.
- ☐ Check pump/motor hardware and all plumbing connections for tightness.
- ☐ Check all electrical terminals and connections for tightness.

Installation

Note: It is recommended that only qualified, experienced personnel, familiar with this type of equipment, who have read and understood all the instructions in this manual should install, operate, and maintain the system.

Mounting

The unit should be permanently wall mounted on a hard, level surface. Use provided mounting holes located on the back plate for proper fastening (Refer to mechanical drawing(s) for Mounting Hole Diameter). Be sure to secure the system in a location that allows all piping and electrical wiring to be safely routed to the system. This unit is designed for well-ventilated indoor use within the specified temperature range and should be located as close to the tank as possible.

Electrical

!WARNING! To avoid the risk of electric shock, make sure that the power supply to the system is disconnected and ensure that the system is at zero volts, before working on any of the system's electrical parts.

Make sure that the system's power requirements and rated voltage/frequency match your electrical system (see wiring diagram). The system may only be connected to properly grounded power sources for operator safety. Connect all components to the ground studs provided as shown on the provided drawings. The system connects to either 12VDC or 24VDC with the positive lead from your power source to the red wire and the negative lead to the gray wire. After the initial wiring of the system check operation to ensure that it is running in the correct direction. If the motor is running in the wrong direction, contact AXI International immediately.

!WARNING! The whole system (enclosure, doors, plumbing, motor, electric sub panel) must be properly grounded for operator safety.

Depending on length of run, use wiring according to specification in wiring diagram and connect system to a separate UL listed breaker (not included) appropriate for branch circuit protection. Connect the System Controller to the filtration unit with the provided plugs and wiring harnesses.

Note: Wiring and electrical installation must be in accordance with all applicable federal, state, and local rules, laws, standards, and regulations.

Plumbing

Note: Please ensure to check all of the plumbing (joints, unions, miscellaneous fittings) for tightness prior to completion.

Use proper quality approved fuel line materials with similar inner diameter (ID) to the inlet/outlet of the system. For extended suction side plumbing runs, it is recommended to install oversized pipe, (1/4" to 1/2" increased ID) (Ref.: Page 4 – Suction Capability). **It is imperative that external, manual inlet and outlet ball valves be installed on each side of the filtration system. That will enable it to be isolated from the external piping apparatus, eliminating the possibility of the system to be damaged by over-pressurization of said plumbing during initial start-up testing (IST).**

Note: Flexible plumbing is strongly recommended for system inlet and outlet connections to external plumbing in order to avoid issues with thermal expansion, prevent putting any stress on the internal fittings of the system, and enable ease of maintenance/installation. Install manual inlet and outlet ball valves prior inlet flexible plumbing and post outlet flexible plumbing respectively.

The pick-up tube/line(s) should originate from the lowest point of the tank to ensure all water is removed. Also, it should be connected directly to the system's inlet port (located on the left-hand side of the system) and be kept as short as possible. It is recommended that an oversized, low restriction foot valve be installed to keep the system primed, especially if the inlet port of the system is located above the lowest possible level of fuel in the tank.

The return line(s) should be plumbed to the system's outlet port (located on the right-hand side of the system) and enter the tank as far as possible away from the pick-up tube, close to the tank bottom.



Multiple suction and/or return lines may be connected to a manifold outside the system.

Note: Anti-Siphon or other external plumbing devices may be required by state and/or local regulations & code.

Cumulatively, the system capabilities are 10 FT. (3.05 m) suction (vertical lift), when connected to the minimum recommended piping size (Ref.: Page 4 – Inlet/Outlet Port), or more, with no additional flow restrictions. That includes valves, 90-degree connectors, or other plumbing accessories. For continuous optimal performance, make sure suction and discharge lines are free of contamination, nothing is blocking the flow of fuel, and the suction line always stays primed.

Note: Plumbing installation must be in accordance with all applicable federal, state, and local rules, laws, standards, and regulations.

Typical Plumbing Installation (Schematically)

See provided P&ID drawing(s).

Important Installation Precautions

The suction line of the system should be independent and separate from the suction line of the engine. If that is not possible, appropriate valves must be installed separate to the system from the engine fuel system to prevent any possible interference with safe engine operation.

It is highly recommended to plumb the discharge line independent and separate of the engine's fuel return line back to the tank. If the return line from the engine and the discharge of the system must be combined in any way, adequate valves should be installed to prevent any possible interference with safe engine operation.



Controller

Setting the Current Date and Time

1. Press and hold the 'CLOCK' button.
2. Proceed to press sequentially, 'DAY', 'HOUR' and 'MIN' button to adjust clock of timer to correct date, hour and minute.

Programming the Timer

1. Press the 'TIMER' button. LCD screen will switch to the first timer (1ON)
2. Press 'DAY' as often as required to select any of the 15 combinations of days that suit your application
3. Press 'HOUR' and 'MIN' respectively to set desired start time for 1ON
4. Press 'TIMER' to switch to 1OFF
5. Press 'DAY' as often as required to select the same combinations of days as in step 2 (must be consistent)
6. Press 'HOUR' and 'MIN' respectively to set desired stop time for 1OFF
7. Repeat procedure (step 1 through 6) if you would like to set several timers
8. When finished programming press 'CLOCK'

To review the program press 'TIMER' button repeatedly to go through all 8 timers.

To activate the timer program, make sure to press 'MANUAL' button will the display indicated you are in AUTO mode.
Please call AXI International with any questions.



Priming the System

The pump supplied with the system is NOT automatically self-priming and must not be run dry.

!WARNING! If the pump is allowed to run without fuel, pump damage will occur.

Priming Procedure

The pump head of the unit is shipped from the factory filled with oil to facilitate initial lubrication. This will not eliminate the necessity to prime the complete system. The system is primed through the priming tee or suction line(s) which have to be completely filled with fuel (no trapped air) prior to the initial system start-up.

The system is equipped with a pressure switch on the output side of the pump. When the pump outlet pressure reaches 15 PSI the system will shut down and activate the “HIGH PRESSURE ALARM”. This indicates excessive debris in the fine filter or a flow restriction.

Commissioning/Initial Start-Up

Gauge Venting

After shipment, gauge pointers may not rest at zero due to internal case pressure build-up, which is caused by temperature and/or pressure variations. As a result, their accuracies may be significantly reduced. To restore the gauges to operating condition, move the yellow lever of the fill plug to the open position or remove the black rubber piece from top of gauge and leave it open to vent.

Switch Adjustments

Note: Please contact AXI International before adjusting either the vacuum or the pressure switch to avoid voiding the system's warranty.

Pressure Switch

When the value exceeds the set point of the switches' rating, the switch will change state. Ensure you are working with a normally closed position (leads on opposite sides of the switch – across from one another are connected to the wire spades). If the set point is incorrect, adjustments can be performed in the field as follows:

1. Remove the two wires connected to the normally closed spades on the top of switch.
2. Pop off the "Rubber Plug" in between the spades on top of the switch.
3. Insert a 5/64" Allen Wrench/Key into the slot.
4. Adjust the Wrench/Key $\frac{1}{4}$ - $\frac{1}{2}$ turn at a time CW to increase the pressure alarm's set point.
5. After adjusting the settings, perform the testing procedure(s) for the switch(es) as outlined in the commissioning section.

Initial Test Procedures

With breakers and power turned on, and pump running, check all alarms for proper operation:

- **Leak Detection** - Manually raise the float switch located at the bottom of the leak-basin. Pump should immediately turn off, and the "Leak Detection" alarm should be indicated on the System Controller. Reset the alarm by pushing or selecting the "Alarm Reset" on the System Controller.
- **High Pressure Alarm** - Slowly, partially close outlet ball valve. At 15 PSI, the pump(s) should turn off and the "High Pressure" alarm should be indicated on the System Controller. Open the outlet ball valve again. Reset the alarm by pushing or selecting the "Alarm Reset" on the System Controller.

Note: If any of the above described alarm test procedures fail or if any alarm trip value deviates, immediately contact AXI International.

Maintenance

The system should be visually inspected and tested a minimum of every six (6) months according to the procedure below during light duty cycles. Monthly inspections are recommended for systems that are being used in excess of an average of eight (8) hours day and five (5) days a week.

Preventative Maintenance

Prior to performing the maintenance procedure ensure that:

1. The electrical sub-panel mounted main disconnect switch is operating properly
2. The user supplied remote circuit breaker is in the "OFF" position
3. All sources of power are isolated from the unit

Note: Proceed only after this has been verified and properly tagged.

4. Check system and all parts for corrosion and rust
5. Check mounting hardware – tighten as necessary
6. Check bolts on the pump/motor hardware for tightness, as pump/motor hardware can loosen after normal operation for extended durations of time, due to vibration.
7. The hardware uses lock nuts – check all bolts for secure nuts
8. Check all electrical terminals and connections for tightness
9. All motors are permanently lubricated and do not require any lubrication
10. Check all plumbing joints for leaks, tighten fittings and joints as necessary, and remove accumulated fuel in leak-basin as necessary
11. Inspect all filter(s) and separator(s)

Note: All filter elements should be replaced at least every six (6) months.

Servicing the Fine Filter

Clogged filter elements restrict the flow of fuel, resulting in the system's pressure gauge indicating a pressure spike. The gauge is mounted between the pump and the fine filter. At a pressure of 15 PSI, the pump will automatically shut off and generate a High Pressure Alarm. This signal indicates that it is time to change the filter element.

Changing the fine filter(s):

1. Press the 'MANUAL' button on the System Controller until 'OFF' is indicated on the display – making sure the pump will not turn on.
2. Close the inlet and outlet ball valves.
3. Place an appropriate container underneath the filter.
4. Remove the old spin-on filter with a filter wrench.
5. Apply a film of lubricating oil to the gasket of the new filter. Screw the new filter canister to the filter head until the gasket is tight and secure (rotate the element an additional 0.5-1.0 turn after the filter makes contact with the gasket).
6. Open the inlet and outlet ball valves.
7. Push or select Alarm Reset on the control panel to acknowledge the alarm and reset it.
8. Return the control panel selector switch to its original position.
9. Press the 'MANUAL' button on the System Controller until 'AUTO' or 'MANUAL' are indicated on the display and check for leaks when re-starting and pressurizing the system.

Note: Disposal of fuel, associated waste, and filters must be in accordance with all applicable federal, state, and local rules, laws, standards, and regulations.

!WARNING! Some fuels may have been treated with biocides. Biocides are extremely toxic and may enter the body through the skin. It is recommended to use adequate protection and proper precautions if fuel contains biocide type products.



Replacement Filter Chart

FPS DX-S FILTERS

All Filters are absolute, unless otherwise noted | wb: waterblock | SS: Stainless Steel Screen

STRAINER Basket	
	50 Mesh
FPS DX-S	Tk-070

Spin-On Filters	
3μ WB	10μ
WBS-3	FFS-10

Troubleshooting

Symptom Troubleshooting Guide

No fuel delivery

1. Pump does not run
2. Pump is not primed
3. Fuel supply line blocked
4. Excessive lift
5. Air leak in fuel supply to pump
6. Pump rotation direction incorrect
7. Intake or outlet valve closed
8. Check valve installed backwards

Insufficient fuel delivered

1. Air leak at inlet
2. Defective pressure relief valve or check valve
3. Excessive lift
4. Pump worn
5. Inoperative foot valve
6. Piping improperly installed or dimensioned

Rapid pump wear

1. Pipe strain on pump causing bind
2. Worn pump/motor coupler
3. Pump has been run dry or with insufficient fuel
4. Plumbing on inlet side not appropriately dimensioned

Alarm “HIGH PRESSURE ALARM” comes on with clean or new filter element installed

1. Heavily contaminated fuel/excessive water in tank
2. Restriction in plumbing on discharge side too high
3. Head on discharge side too high
4. Check valve stuck or defective
5. Outlet ball valve not fully open
6. Discharge line clogged

Pump requires too much power

1. Air in plumbing lines
2. Liquid too viscous
3. Bent pump shaft, binding rotor
4. Misalignment of pump/motor coupler

Noisy operation

1. Insufficient fuel supply
2. Air leaks in the inlet pipe
3. Air or gas in fuel on the suction side
4. Pump and motor out of alignment
5. Worn out spider coupling
6. Pump coupler out of balance

Motor does not turn or turns intermittently

1. Control power not available
2. Motor thermal overload condition
3. Pump failed and seized
4. Motor failure

Pump leaks fuel

1. Loose pump plumbing fittings
2. Worn pump shaft seal
3. Pump pressure relief valve failure
4. Fuel leak elsewhere and fuel dripping or running towards the pump
5. Excessive head from overhead storage tank
6. Worn pump O-rings or seals

AXI International Limited Warranty

AXI International makes every effort to assure that its products meet high quality and durability standards and expressly warrants the products described herein against defects in material and workmanship for a period of one (1) year from the date of purchase. This warranty is not intended to supplant normal inspection, care and service of the products covered by the user, and shall not obligate AXI International to provide free service during the warranty period to correct breakage, maladjustment, or other difficulties arising out of abuse, misuse, or improper care and maintenance of such products. Our express warranty is subject to the following terms and conditions:

This warranty shall only extend to and is only for the benefit of original purchaser(s), or end customer(s) who use the products covered hereby and subject to the terms and conditions herein. This warranty is not an on-site warranty. Travel requests will be at the discretion of AXI International. Defective systems and ancillary products will require a return authorization number and shipping to AXI International's factory in Fort Myers, FL. Any warranty claim received by AXI International after one (1) year from the date of purchase will not be honored even if it is claimed that the defect occurred prior to one (1) year from the date of purchase. Claims outside of this one (1) year period, and for claims not listed within, payment, repair, or service will be awarded at the sole and exclusive discretion of AXI International.

This Warranty shall NOT apply to the following:

1. Damage or deterioration caused by normal wear and tear.
2. Failures caused by any external cause or act of God, such as accident, collision, theft, vandalism, riots, wars, re, freezing, lightning, earthquakes, windstorms, hail, volcanic eruptions, floods, tornados or hurricanes.
3. Failures due to alterations, adjustments, unauthorized changes to the product(s), neglect or improper storage, repair and/or maintenance.
4. Failures due to abuse or application of the product(s) for uses other than for which it/they are designed or intended by AXI International, including but not limited to, improper installation or location in a harsh, corrosive or saltwater environment.
5. Failures resulting from attachments, accessory items, and parts not sold by AXI International.
6. Repairs by any party other than those authorized by AXI International.
7. Failures resulting from user's delay in making the product available for inspection by AXI International after notifying AXI International of a potential product problem.
8. Cosmetic damage, discoloration, rusting, corrosion or scratches from applied paint.
9. Replacement of consumables such as, but not limited to, fuses, lamps, filters, etc.
10. Additional expenses for repair after normal business hours, i.e., overtime or holiday labor rates.
11. Expenses for rental of equipment during downtime and/or performance of warranty repairs.
12. Expenses related to investigating performance complaints and/or troubleshooting where no manufacturing defect is found.

In addition to the limitations above, this warranty shall not apply to products (1) which have been tampered with, altered or repaired by anyone other than AXI International without the express prior written consent of AXI International (2) which have been installed improperly or subject to misuse, abuse, accident, negligence of others, improper operation or maintenance, neglect or modification, or (3) which have had the serial number altered, defaced or removed.

The liability of AXI International under this warranty is limited to the repair or replacement of the defective product. AXI International assumes NO LIABILITY for labor charges or other costs incurred by any purchaser incidental to the service, adjustment, repair, return, removal or replacement of products. AXI INTERNATIONAL ASSUMES NO LIABILITY FOR ANY GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, CONTINGENT OR OTHER DAMAGES UNDER ANY WARRANTY, EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WITH THE RESPECT TO THE PRODUCTS COVERED BY THIS WARRANTY POLICY, EXCEPT AS EXPRESSLY PROVIDED FOR HEREIN. AXI INTERNATIONAL ASSUMES NO LIABILITY FOR ANY GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, CONTINGENT OR OTHER DAMAGES EVEN IF SUCH DAMAGES ARE A DIRECT RESULT OF AXI INTERNATIONAL'S NEGLIGENCE. NO EMPLOYEE, AGENT, REPRESENTATIVE OR DISTRIBUTOR IS AUTHORIZED TO MAKE ANY WARRANTY ON BEHALF OF AXI INTERNATIONAL OTHER THAN THE EXPRESS WARRANTY PROVIDED FOR HEREIN.

AXI International reserves the right at any time to make changes in the design, material, function and specifications of its products. Any such changes shall not obligate AXI International to make similar changes in such products that were previously manufactured.



To the fullest extent permitted by law, any claims against AXI International are limited to the remedies as expressly set forth in this warranty and any other further claims, such as but not limited to, compensation for any damage incurred other than to the AXI International product, are hereby excluded.

Warranty Claim Procedure

To make a claim under this warranty, please call AXI International at +1-239-690-9589 or 1-877-425-4239, and provide: Name and location where unit was purchased, the date and receipt of purchase, model number, serial number, and a detailed explanation of the problem you are experiencing. The Customer Service Representative may, at the discretion of AXI International, arrange for a Field Engineer to inspect your system. If the inspection reveals a defect covered by its limited warranty, AXI International will either repair or replace the defective parts or products. AXI International assumes no liability, if upon inspection, AXI International or its representative determines that there is no defect or that the damage to the system resulted from causes not within the scope of this limited warranty and customer shall be responsible standard rates incurred by AXI International, as established from time to time by AXI International.

For service and sales, please contact AXI International:

AXI International | 5400 Division Drive Fort Myers, FL 33905
Tel: +1-239-690-9589 | Toll Free: +1-877-425-4239 | Fax: +1-239-690-1195
Email: info@axi-international.com | Internet: www.axi-international.com



Technical Assistance and Ordering

Please write, fax, email or call:

AXI International
5400 Division Drive
Fort Myers, FL 33905
Tel: +1-239-690-9589
Fax: +1-239-690-1195
Email: info@axi-international.com Internet: www.axi-international.com

Please provide the following information:

Serial Number of your FPS DX-S, the required part numbers and quantity. The drawings/parts list included in this manual are the most accurate source of part numbers for your FPS DX-S.

Replacement Filter Elements

Basket Strainer:

TK-070 – 50 Mesh Strainer

Fine Filter:

WBS-3 - 3 μ Water Block Filter

FFS-10 - 10 μ Fine Filter

FPS DX-S System Identification

Serial Number: _____ (e.g. B090010-DX-S)

Inspected By: _____ Date: _____