




FUEL FLOW METERS



DFM Marine 1000/2000/4000

OPERATION MANUAL **(includes Service DFM Marine software manuals)**

Version 2.0



Contents


Contents	Ошибка! Закладка не определена.
Revision history	4
Structure of external links	5
Terms and Definitions	6
Introduction	8
1 DFM Marine general information and technical specifications	10
1.1 Purpose of use and application area	10
1.2 Exterior view and delivery set	13
1.3 DFM Marine models	14
1.3.1 Autonomous fuel flow meters with display	14
1.3.2 Fuel flow meters with display and interface cable	15
1.4 Measurement range and accuracy	16
1.5 Unit structure and operation principle	17
1.6 Technical specifications	19
1.6.1 Working fluids	19
1.6.2 Main specifications	20
1.6.3 Specifications of measuring chambers	21
1.6.4 Power supply modes	22
1.6.5 Operation modes	23
1.6.6 Displayed data	24
1.6.7 DFM Marine protection from tampering and intervention	28
1.6.8 Pulse output signal specifications	29
1.6.9 CAN/S6 output interface specifications and protocol	30
1.7 DFM Marine and tracking devices compatibility	32
1.8 DFM Marine selection	33
1.8.1 Selection depending on engine power (boiler output capacity)	33
1.8.2 Selection depending on fuel flow rate in supply and return lines of the engine ..	34
2 DFM Marine installation	35
2.1 Exterior inspection prior to works start	35
2.2 Estimation of the fuel consumer condition	36
2.3 General installation instructions	37
2.4 Example schemes of flow meter installation into fuel line	40
2.5 Electrical connection	45

2.6 Fuel flow meters configuration	48
2.6.1 Connecting DFM Marine to PC	48
2.6.2 User interface	52
2.6.3 User authorization	53
2.6.4 Working with DFM profile	54
2.6.5 Configuration for connection to external terminal unit.....	56
2.6.6 Operation check	57
2.6.7 Configuration for specific operation conditions	58
2.6.8 Differential/summarization operation mode	60
3 Measurement accuracy check	61
3.1 Test conditions	61
3.2 Conducting the tests	62
4 Registered Events control	63
5 Diagnostics and troubleshooting	64
6 Verification	65
7 Maintenance.....	66
8 Packaging	67
9 Storage	68
10 Transportation	69
11 Utilization/re-cycling.....	70
Contacts.....	71
Annex A Overall dimensions and weight	72
Annex B Protocol of inspecting machinery unit	74
Annex C Template of check test report	75
Annex D Signal cables.....	76
Annex E DFM Marine CAN connection options	77
Annex F SPN of DFM Marine Functional modules	81
Annex G DFM Marine firmware upgrade	90
Annex H DFM Marine mounting plate drawing	91
Annex I Videos	92

Revision history

Version	Date	Editor	Description of changes
1.0	08.2007	OD	Basic version.
2.0	09.2017	OD	<ul style="list-style-type: none">• DFM Marine paired measurement modes are added – differential and summarization of fuel consumption.• DFM Marine CCAN data transfer protocol description is updated with new PGN.• FM Flowmeter (v.3) is updated with new PGN, which are displayed and/or edited with Service DFM Marine (v 1.6) software.• New screens of DFM Marine CCAN flow meters display are added.• Exterior of DFM Marine is changed.• Mounting holes placement schemes are added.• Dimensions and weight of DM Marine are updated.• Structure of external links of this manual is added.

Structure of external links



Terms and Definitions

ORF 4 — is the Telematics service by JV Technoton developed for receiving and processing Onboard reports via Internet, displaying Operational Data overlapped on area maps, information storage in database and Analytical reports generation upon user's request.



S6 — is the vehicle onboard data bus developed by **TECHNOTON** to enable integrating the GPS/GLONASS-based vehicle monitoring system into the vehicle electrical equipment. It comprises a set of cables, interfaces and protocols. Physically, it is implemented on the basis of CAN 2.0B (ISO 11898-1:2003) and K-Line (ISO 9141). S6 bus data exchange protocol complies with SAE J1939 International Standard. To get more details on S6 Telematics bus visit <http://s6.jv-technoton.com/en/>



Information on cabling system, service adapter and S6 software refer to [S6 Operation manual](#).

PGN (Parameter Group Number) — is a combined group of S6 parameters, which has common name and number. Functional modules (FM) of the Unit can have input/output PGNs and setup PGNs.

SPN (Suspect Parameter Number) — informational unit of S6. Each SPN has determined name, number, extension, data type and numerical value. The following types of SPN exist: Parameters, Counters, Events. SPN can have a qualifier which allows qualification of parameter's value (e.g. – Onboard power supply limit/Minimum).

Analytical report — report generated in ORF 4 on vehicle or group of vehicles operation for chosen time period (usually a day, week or month). Can be composed of numbers, tables, charts, mapped route of vehicle, diagrams.

Onboard equipment (OE) — Telematics system elements, directly installed in Vehicle.

Onboard reports (the Reports) — information about vehicle which is returned to a user of Telematics system in accordance with inputted criteria. The Reports are generated by a terminal unit both periodically (Periodic reports) and on Event occurrence (Event report).

GNSS (Global Navigation Satellite System) — System for area positioning of an object through satellite signal processing. GNSS is composed of space, ground and user segments. Currently, there are several GNSSs: GPS (USA), GLONASS (Russia), Galileo (EU), Compass (China).

Route — data massive, consisting of coordinates, speed and direction of vehicle's movement. Corresponds to a real route of the vehicle. Depicted as lines on the Map. Direction of vehicle's movement is depicted by arrows.

Parameter — time-varying or space characteristic of the Vehicle (SPN value). For example, speed, fuel volume in the tank, hourly fuel consumption, coordinates. Parameter is usually displayed in the form of graph, or averaged data.

Server (AVL Server) — hardware-software complex of Telematics service ORF 4, used for processing and storage of Operational data, formation and transmission of Analytical reports through Internet by request of ORF 4 users.

Event — relatively rare and sudden change in SPN. For example, the attempt to falsify values of “Instant fuel consumption” counter by applying electromagnetic field to fuel flow meter will be recognized as “Interference” Event. An Event can have one or several characteristics. “Interference” Event has the following: date/time and duration of interference. When the Event occurs, a terminal unit registers the time of occurrence, which is later mentioned in a report on the event. Thus, the Event is always attached to exact time and place of occurrence.

Counter — cumulative numerical characteristics of Parameter. Counter is represented by a number, which can only grow in time. Examples of Counters: fuel consumption, engine operation time, total distance and other.

Telematics system — complex solution for real-time and after trip vehicle monitoring and control. Main vehicle parameters monitored: route, fuel consumption, operation time, technical condition of vehicle, safety. Consists of OE, Communication channels, Telematics Service ORF 4.

Vehicle — an object controlled within Telematic system. Usually Vehicle means a truck, tractor or bus, sometimes a locomotive or river boat. From Telematic system point of view, stationary objects are also considered to be vehicles: diesel gensets, stationary tanks, boilers/burners.

Function module (FM) — unit-embedded component of hardware and software combination, executing a group of special functions. Uses input/output PGNs and settings PGNs.

Unit — an element of Onboard Equipment of Vehicle, which is connected to Telematics Interface S6. Particularly, in this document Unit means DFM Marine fuel flow meter.

Introduction


The Operation manual contains guidelines and rules which refer to **DFM Marine fuel flow meters** (hereinafter [DFM Marine](#)), developed by JV [Technoton](#), Minsk, Belarus.

The manual contains information on design, operation principle, specifications and instructions on installation, use and maintenance of DFM. The manual provides guidelines on DFM configuration with Service DFM Marine software (version 1.6 and higher).



— precise tool for fuel consumption measurement of vessels, locomotives, high-power diesel generators, burners, mining and quarrying machinery. DFM Marine could be used both as a part of [Telematics system](#) and autonomously.


DFM Marine features:

- conformity with European and national standards and directives;
- recording real fuel consumption and operation time of fuel consumer – total and in different consumption modes: “Idle”, “Optimal”, “Overload”, “Tampering” and “Interference”;
- could be used for differential measurement or summarization of fuel consumption data when flowmeters are used in pair and connected using CAN/S6 technology*;
- protection against unauthorized interference in operation and data “tampering”;
- maximum information richness of output data*;
- high reliability of data transmission over digital interfaces*;
- unique self-diagnostics feature to monitor the stability and accuracy of data*;
- possibility of integration into on-board  [Telematics interface](#) *;
- embedded battery allows data ([Counters](#), [Events](#)) storage in the internal non-volatile memory of flow meter;
- thermal correction function with adjustable coefficient which ensures automatic correction of values to the ambient temperature**;
- easiness of flow meter configuration with S6 SK service kit, which is similar for all Onboard Equipment based on S6 Interface**;
- installed in fuel line using thread or flange connection elements;
- electronic part of DFM Marine can be disconnected without dismounting flow meter from the fuel line;
- straight segments of fuel line are not necessary for flow meter installation;
- accuracy of measurement is not decreasing when flow meter is operated in tough operation conditions;
- minimum fluid flow resistance;
- 100 % of DFM are verified with a certified metrological test rig;
- high-quality technical support, affordable price.

* For DFM Marine CAN.

** For DFM Marine with interface cable.

See figure 1 for identification codes for DFM Marine ordering:



* Interfaces: RS-232 (protocol DUT-E COM (LLS)) and RS-485 (protocol Modbus) - under the order

Figure 1 — DFM Marine order identification codes

Example of DFM Marine order identification codes:

«DFM Marine 1000C FL Fuel flow meter»,
 (max. flow rate — 1000 l/h, autonomous with display, with flange connection, material — brass).

«DFM Marine 2000CK TL Fuel flow meter»,
 (max. flow rate — 2000 l/h, with output normalized pulse, with thread connection, material — brass).

«DFM Marine 4000CCAN FA Fuel flow meter»,
 (max. flow rate — 4000 l/h, output interface — CAN/S6, with flange connection, material — duralumin).

For [DFM Marine](#) with output interface configuration a service adapter is used (S6 SK or SK DFM), which is ordered additionally, and software Service DFM Marine you can download and/or update your Service DFM Marine software at <http://www.jv-technoton.com/>, in [Software/Firmware](#) category.



ATTENTION: It is strongly recommended to follow strictly the instructions of the present Manual when using, mounting or maintaining DFM Marine.


The Manufacturer guarantees DFM Marine compliance with the requirements of technical regulations subject to the conditions of storage, transportation and operation set out in this Manual.



ATTENTION: Manufacturer reserves the right to modify DFM Marine specifications that do not lead to a deterioration of the consumer qualities without prior customer notice.

1 DFM Marine general information and technical specifications

1.1 Purpose of use and application area

 is designed for fuel consumption measurement in fuel lines of powerful engines of vehicles and stationary units (see figure 2).






Figure 2 — DFM Marine purpose of application

Application area — DFM Marine fuel flow meters are used both as a part of [Telematics systems](#) and as a stand-alone solution (see figure 3).



a) example of DFM Marine application within Telematics system



c) example of DFM Marine application within S6 Telematics interface*

Figure 3 — Examples of DFM Marine fuel flow meters application

[DFM Marine](#) are mounted into fuel supply line of the engine/burner/boiler and measure actual (instant) fuel consumption rate and generates an output signal to forward it to a vehicle tracking device (see figure 3 a).

Terminal unit gathers, registers, stores received signals and transfers them to telematic Server. Software installed on the [Server](#) generates [Analytical reports](#), which allow time-related [Route](#) control and [Vehicle](#) fuel consumption monitoring via web-browser (see figure 4).

DFM Marine models are presented in [1.3](#).

When using **autonomous DFM Marine** fuel consumption and vehicle operating time data (overall and in different engine operation modes) is displayed on the built-in LCD display (see figure 3 b).

DFM Marine with pulse output interface provide data on actual fuel consumption of engine (overall fuel consumption and average instant fuel consumption).

DFM Marine with CAN/S6 interface provide real-time control over extended set of information:

- instant fuel consumption;
- differential/ summary fuel consumption in two fuel lines**;
- engine operation time – overall and in different engine operation modes;
- fuel consumption – overall and in different engine operation modes;
- voltage in on-board power network;
- total operation time of flow meter and duration of power-supply from embedded battery;
- flow meter's malfunctions;
- evidence of interference to flow meter's operation.

* Only for DFM Marine CAN.

** When used a pair of DFM Marine.

Using J1939 output protocol makes possible DFM Marine CAN operation as a part of **S6 Telematics interface** together with **DUT-E CAN** fuel level sensors and other factory-built or additional equipment (see figure 3 c). Tracking device with a single CAN interface port can receive data from up to 8 DUT-E CAN sensors and up to 8 DFM Marine CAN meters. This possibility is especially useful while objects with several engines (river boats, locomotives, technological vehicles, diesel genset stations) are equipped.




Figure 4 — Example of Analytical Report generated in ORF 4 software, based on the DFM Marine CAN data

Use of **DFM Marine** provides vehicle owners with the following:

- actual fuel consumption records;
- registration of machinery working time;
- normalizing of fuel consumption quotas;
- fuel theft detection and prevention;
- real-time monitoring and fuel consumption optimization;
- fuel consumption tests for engines.

1.2 Exterior view and delivery set



- | | | |
|---|--|----------|
| 1 | DFM Marine fuel flow meter | - 1 pc.; |
| 2 | iButton key | - 1 pc.; |
| 3 | 7.5m signal cable DFM 98.20.003 (7.5 m)* | - 1 pc.; |
| 4 | Verification certificate | - 1 pc.; |
| 5 | DFM Marine specification sheet, including screen description | - 1 pc.; |
| 6 | Fuse with holder (2 A)** | - 1 pc. |

Figure 5 — DFM Marine delivery set

* Only for DFM Marine CK meters with pulse interface output.

For DFM Marine CAN, S6 SC-CW-700 signal cable (see [2.5](#)) is purchased separately.

** Not applicable for autonomous DFM fuel flow meters.

1.3 DFM Marine models

Fuel flowmeters DFM Marine is represented by the following models:

1) By output interface:

- autonomous fuel flow meters with display;
- fuel flow meters with display and interface cable:
 - with pulse output;
 - with digital CAN/S6 (SAE J1939) interface.

2) By connection type to fuel line:


- flange – according to DIN 2501;
- thread – according to DIN 259, ISO R228.

3) By type of body and connection materials:

- duralumin;
- brass.

1.3.1 Autonomous fuel flow meters with display

Autonomous fuel flow meters with display (DFM Marine C models) — are used in organizing fuel consumption monitoring system which does not need additional hardware or software (see figure 6).



a) with thread type of connection

b) with flange type of connection

Figure 6 — Exterior of autonomous fuel flow meters with display

with thread type of connection

Fuel consumption and vehicle operating time data is displayed on the built-in LCD display. Monitoring and recording is to be performed visually, copying out the data into a fuel timesheet, by a responsible person.

1.3.2 Fuel flow meters with display and interface cable

Fuel flow meters with display and interface cable (DFM Marine CK/CCAN models) (see figure 7) can be used autonomously and as a part of the [Telematics system](#).



a) with thread type of connection

b) with flange type of connection

Figure 7 — Exterior of fuel flow meters with display and interface cable

Fuel consumption and vehicle operating time data is displayed on the built-in LCD display. Fuel consumption data is sent to the pulse output as well (**DFM Marine CK**). In CAN/S6 digital interface (**DFM Marine CCAN**) contain fuel consumption data together with [Counters](#) values, data on engine operation modes, flow meter settings and malfunctions, [Events](#).

1.4 Measurement range and accuracy

Table 1 — Measurement range and accuracy of [DFM Marine](#) flowmeters

Model (by size)	Starting flow rate*, m ³ /h	Minimum flow rate, m ³ /h	Maximum flow rate, m ³ /h	Relative accuracy error, %, not more than***
DFM Marine 1000	0.01	0.02	1	±0.5**
DFM Marine 2000	0.02	0.04	2	
DFM Marine 4000	0.04	0.08	4	

* Minimum threshold flow rate value when the meter starts operating.
The value is indicated for reference only as accuracy is not standardized for operation on the starting flow rate.

** In differential/summarization measurement mode, inaccuracy is not higher than ±1.0 % (depending on the proportion of fuel consumption in chamber of each flow meter used).

*** If fuel consumption is below 0.05 m³/h, the allowed inaccuracy is not more than ±1.0 %, for differential/summarization fuel consumption modes – not more than ±2.0 %.



RECOMMENDATION: In case the average flow rate in engine is close to the upper capacity limit of a certain DFM Marine model it is recommended to use DFM Marine with a higher measurement range. That will ensure absence of a fuel flow meter's influence on the fuel system as well as longer DFM Marine operating life.

1.5 Unit structure and operation principle

[DFM Marine](#) consists* of a ring-type measuring chamber (1), measuring "head" with display and with electronic unit inside (2), body with connection (flanged or threaded) (3), interface output cable with connector (4) (see figure 8).




Figure 8 — DFM Marine components

DFM Marine is a direct volumetric fuel consumption measurement device with ring-type measuring chamber.

The principle of DFM Marine operation is based on measurement of fuel volume that passes through its measuring chamber. Because of the pressure of the fuel coming to the measuring chamber through the inlet fitting the ring slides along the inner surface of the chamber and along the jumper at the same time. The ring pushes the fluid inside and outside itself out to the outlet fitting (see figure 9).

Volume of fluid equal to the inner volume of the measuring chamber is pushed out during the full single turn of the ring (see animation on [DFM fuel flow meter operational principle](#)). DFM Marine electronics generates one output impulse at the same time.



Figure 9 — DFM Marine measuring chamber operation scheme

* Structure is shown in an instance of one-chamber DFM Marine CK with built-in display and interface output.

When [DFM Marine](#) is used within [Telematics system](#), signal cable is connected to an appropriate input of telematic terminal (logging device).

Distinctive design features of DFM Marine fuel flow meters:

- DFM Marine structure provides fluid flow even in case the ring is blocked (e.g. as a result of clogging of the chamber);
- special coating of the ring ensures its durability and wear resistance;
- measuring chamber is made of brass, which is durable and corrosion-proof;
- straight segments of fuel line at input and output of flow meter are not necessary for correct operation of measuring chamber;
- electronic part of DFM Marine can be disconnected without dismounting flow meter from the fuel line;
- increased nominal bore for minimum fuel flow hydraulic resistance;
- DFM Marine sensitivity to hydraulic shocks in fuel line is decrease by improved magnetic scheme and broad configuration options (with service software), also allowing to achieve higher accuracy.

1.6 Technical specifications

1.6.1 Working fluids

[DFM Marine](#) can be used for following fluids flow measurement:

- diesel fuel;
- heating oil
- burner oil;
- motor fuel;
- biofuel;
- other liquid fuels and mineral oils with kinematic viscosity of **1.5 to 6.0 mm²/s**.

ATTENTION:



- 1)** All DFM Marine units are verified with diesel fuel. Indicate viscosity when ordering DFM Marine for measuring different fluid type.
- 2)** When operating with fluids having kinematic viscosity over 6 mm²/s the upper limit of DFM Marine capacity range will get lower than nominal one and the pressure drop will increase.
- 3)** Foreign inclusions size in the liquid should not be more than 0.250 mm (for DFM Marine 1000) and 0.400 mm (for DFM Marine 2000 and DFM Marine 4000).
- 4)** DFM Marine flow meters are made of petrol resistant materials. However, the declared lifetime of the measuring chamber is not guaranteed when operating with petrol (see [1.6.3](#)).

1.6.2 Main specifications

Table 2 — [DFM Marine](#) main specifications

Parameter, measurement units	Value		
	DFM Marine 1000	DFM Marine 2000	DFM Marine 4000
Maximum pressure for flange connection, bar	25		
Maximum pressure for thread connection, bar	16		
Nominal pressure, bar	2		
Type of connection thread	G3/4-A	G1-A	G1 1/4-A
Distance of flange holes, mm	65	75	85
Supply voltage range, V	from 10 to 45		
Current consumption at 12 V, mA, not more than	50		
Current consumption at 24 V, mA, not more than	25		
Ambient operation temperature range, °C	from -20 to +60		
Vibration resistance	Max. acceleration to 100 m/s ² in the frequency range from 5 to 250 Hz		
Resistance to aggressive environments	Oil and petrol resistance		
Electromagnetic compatibility	<ul style="list-style-type: none"> • ESD Protection, severity level II; • electromagnetic interference protection, severity level IV. 		
Ingress protection rating	IP54		
Overall dimensions	see annex A		
Weight			

1.6.3 Specifications of measuring chambers

Table 3 — Specifications of [DFM Marine](#) measuring chambers

Flow meter capacity model	Nominal diameter (DN), mm	Nominal volume of the measuring chamber, ml	Re-calibration interval *, m ³
DFM Marine 1000	15	30	1200
DFM Marine 2000	20	75	2800
DFM Marine 4000	25	150	5250
* See 7			

1.6.4 Power supply modes

[DFM Marine](#) fuel flow meters can operate in the following power supply modes:

- **Stand-alone power supply (DFM Marine C models)** DFM Marine is powered from the built-in lithium-silicon battery. Estimated DFM Marine operation time until full battery discharge is not less than 36 months.
- **Combined power supply (DFM Marine CK/CCAN models)** — DFM Marine is powered from the external power source or built-in battery (in case external power is off). Power supply is switched to stand-alone mode in case of low level of external power supply (less than 8 V). Estimated DFM Marine operation time in this mode is not less than 36 months.



ATTENTION: During the time when power supply from vehicle on-board power network is off **DFM Marine CK/CCAN** automatically enable option of data readings recording into internal meter memory. When powered from internal battery this fuel flow meters can display data according to [table 5](#). Data transfer to the output interface starts only when external power supply from vehicle on-board network is provided.

1.6.5 Operation modes

Table 5 — Operation modes of [DFM Marine](#) fuel flow meters

Engine operation			Interference The impact of constant magnetic field	
Normal consumption $Q_0 < Q \leq Q_{\max}$		Tampering $Q > Q_{\max}$		
Idle $Q_0 < Q < 2.5Q_{\min}$	Optimal $2.5Q_{\min} \leq Q < 0.75Q_{\max}$			Overload $0.75Q_{\max} \leq Q \leq Q_{\max}$
<div><div>Q</div><div>— instant consumption;</div></div> <div><div>Q_0</div><div>— starting flow rate;</div></div> <div><div>Q_{\min}</div><div>— lower limit of the meter capacity range;</div></div> <div><div>Q_{\max}</div><div>— upper limit of the meter capacity range.</div></div>				



WARNING: Operation mode boundaries of flow meters with pulse output interface can be adjusted via Service S6 DFM software at [FM](#) Flowmeter Marine section (see [annex F](#)).

1.6.6 Displayed data

Display information (see table 5) switching is performed by light touch to lower part of measuring head of the fuel flow meter by iButton key (see figure 10).




Figure 10 — Switching DFM Marine display information screens

In order to save the charge of the built-in battery the [DFM Marine](#) display goes to sleep mode one minute after the last touch of the cover by the iButton. At the same time dots are shown on the display (see figure 11).



Figure 11 — Display view in sleep mode

When the display is touched next time, it wakes up and shows data again.

Table 5 — *DFM Marine* display information screens

Screen No	Displayed data	Digit capacity		Units	
		Metric System of Measures	American System of Measures	Metric System of Measures	American System of Measures
1	Total Fuel Consumption counter	10E-4	10E-2	m ³	gal
2	Total Fuel Consumption counter with higher digit capacity	10E-6	10E-4	m ³	gal
3	Engine Operation Time counter	0.1	0.1	h	h
4	Engine Operation Time in Idle Mode counter	0.1	0.1	h	h
5	Engine Operation Time in Optimal Mode counter	0.1	0.1	h	h
6	Engine Operation Time in Overload Mode counter	0.1	0.1	h	h
7	Engine Operation Time in Tampering Mode counter	0.1	0.1	h	h
8	Engine Operation Time counter. Clearable	0.1	0.1	h	h
9	Total Fuel Consumption counter. Clearable	10E-4	10E-2	m ³	gal
10	Total Fuel Consumption counter. Tampering Mode	10E-4	10E-2	m ³	gal
11	Interference Time counter	0.1	0.1	h	h
12	Instant Fuel Consumption	10E-2	10E-1	m ³ /h	gal/h
13*	Total Differential Fuel Consumption counter	10E-4	10E-2	m ³	gal
14*	Total Differential Fuel Consumption	10E-2	10E-1	m ³ /h	gal/h
15	Battery Charge in Percentage of the Maximum	1	1	%	%
16	Temperature in the Measuring Chamber	1	1	°C	°F
17	Firmware Version	-	-	-	-
* Only for DFM Marine CCAN.					

Screen 1 displays **Total Fuel Consumption** counter value (accuracy of display — $10\text{E-}4 \text{ m}^3/10\text{E-}2 \text{ gal}$) accumulated since DFM Marine release.

Screen 2 displays **Total Fuel Consumption counter value with higher digit capacity** (accuracy of display — $10\text{E-}6 \text{ m}^3/10\text{E-}4 \text{ gal}$), accumulated since DFM Marine release.

Screen 3 displays the counter reading **Engine Operation Time** accumulated as the total time of engine operation in all modes including idle run.

Screens 4, 5, and 6 display the counter readings of **Engine Operation Time In Idle, Optimal and in Overload Modes** accumulated by DFM Marine as a total engine operation time in corresponding modes (see [1.6.5](#)).

Screen 7 displays the counter readings of **Fuel Consumption In Tampering Mode** accumulated by DFM Marine as a total time of engine operation when consumption was higher than maximum possible (see [1.6.7](#)). Value increase of this counter indicates the incorrect installation of the fuel flow meter or possible facts of fuel theft.

Screen 8 displays the counter readings of **Engine Operation Time. Clearable**, which was accumulated as a total time of engine operation in all modes, including idling. Counter data could be reset using service software or by applying a magnetic key to a switching zone of DFM Marine's cap when Screen 8 is active.

Screen 9 displays the counter readings of **Total Fuel Consumption. Clearable**, which was accumulated by DFM Marine since its production. Counter data could be reset using service software or by applying a magnetic key to a switching zone of DFM Marine's cap when Screen 9 is active.

Screen 10 displays the counter readings of **Total Fuel Consumption. Tampering Mode** accumulated by DFM Marine measured as the amount of fuel higher than maximum consumption (see [1.6.7](#)). Value increase of this counter indicates the incorrect installation of the fuel flow meter or possible facts of fuel theft.

Screen 11 displays the counter reading **Interference Time** accumulated by DFM Marine as the total time of exposure to external factors (strong magnetic field). Increase of the values of this counter may indicate an installation of the fuel flow meter near a source of strong electromagnetic radiation or deliberate attempts to lock the fuel meter (see [1.6.7](#)).

Screen 12 Instant Fuel Consumption displays current value of fuel consumption. It can serve for a visual check of device operability and its correct installation.

Screen 13 displays **Total Differential Fuel Consumption** counter value (accuracy of display — $10\text{E-}4 \text{ m}^3/10\text{E-}2 \text{ gal}$), accumulated in differential mode (see [2.6.8](#)) by DFM Marine installed in fuel supply line, while used in pair with DFM Marine installed in fuel return line.

Note — If DFM Marine installed in fuel return line is disconnected, the Counter will stop increasing. In this case, flow meter's display will show screen similar to "Tampering" mode screen (see figure 12).

Screen 14 Total Differential Fuel Consumption displays current differential fuel consumption (a difference between fuel consumption in chamber of each flow meter) on display of DFM Marine installed in fuel supply line and operating in pair with DFM Marine installed in fuel return line.

Note — if DFM Marine installed in fuel return line is disconnected, current differential fuel consumption will not be displayed. Flow meter's display will show screen similar to "Tampering" mode screen (see figure 12).

Screen 15 Battery Charge in Percentage of the Maximum displays the value of remaining charge of integrated battery.

Note — When the environment temperature is below 10 °C, displayed value of remaining charge can decrease by (10...30) %.

Screen 16 Temperature in the Measuring Chamber displays current temperature value in the measuring chamber of the fuel flow meter.

Screen 17 Firmware Version displays the firmware version installed on the fuel meter.

1.6.7 DFM Marine protection from tampering and intervention

In order to avoid false readings, meter damage or blocking [DFM Marine](#) have the following modes of protection against malicious acts of third parties:

1) Tampering Mode is to protect from tampering which has a purpose to increase fuel consumption counters readings (e.g. blowing with air). Tampering usually causes a rapid increase of readings exceeding maximum flow rate limit. DFM Marine electronics registers this increase and suspends fuel consumption counters. At the same time Tampering counter is activated. It records volume value that passes through the meter at the increased flow rate.

DFM Marine displays dashes being in Tampering Mode (see figure 12).



Figure 12 — Display view in Tampering Mode

The meter will automatically exit Tampering Mode in few seconds since back to normal operation conditions.

2) Interference Mode is made to protect DFM Marine from magnetic field impact with the purpose to stop fuel counting or to tamper readings of fuel consumption. When exposed to external magnetic field, DFM Marine registers an attempt of interference, and as the result increment of all the counters stops, and the time of exposure is recorded in a special Interference Time counter.

DFM Marine displays vertical strokes in Interference Mode (see figure 13).



Figure 13 — Display view in Interference Mode

The meter will automatically exit Interference mode in few seconds since back to normal operation conditions.



ATTENTION: Data on events of Tampering/Interference during the external power supply of DFM Marine is off is recorded into the internal memory and sent to output interface since the power supply is on.


3) Stand-alone power supply mode for models **DFM Marine CK/CCAN** when external power supply is off. Flow meter is powered by own battery. Embedded battery ensures autonomous functioning within 36 months.



RECOMMENDATION: sealing all connection in fuel line after DFM Marine can help Vehicle owner to reveal unauthorized intervention in fuel line. Valves, bolts and other elements in Technoton-branded mounting kits for DFM Marine has special holes for sealing.

1.6.8 Pulse output signal specifications

Fuel flow meters with **normalized pulse output (DFM Marine CK)** generate certain number $N_{\text{pulse/l}}$ of output pulses for 1 liter of measured fuel flow (see table 6). This number is indicated in product specification as well.



$U_{\text{HIGH}} = U_{\text{BATT}}$ (not more than 36 V);
 U_{BATT} - voltage of on-board electrical system;
 $U_{\text{LOW}} \leq 0,7 \text{ V}$;
 t_{LOW} and T_{imp} see table 6.

Figure 18 — Pulse output signal shape of DFM Marine CK models

Table 6 — Parameters of normalized pulse of DFM Marine CK models

Model	T_{pulse} , ms	t_{LOW} , ms	$N_{\text{pulse/liter}}$, pcs
DFM Marine 1000CK	from 100 to 5400	if $T_{\text{pulse}} < 1\text{s}$, then $t_{\text{LOW}} = 0.5 \cdot T_{\text{pulse}}$ if $T_{\text{pulse}} > 1\text{s}$, then $t_{\text{LOW}} = 500 \text{ ms}$	33.333 (1 pulse equal to 30 ml)
DFM Marine 2000CK	from 135 to 6750		13.333 (1 pulse equal to 75 ml)
DFM Marine 4000CK	from 135 to 6750		6.666 (1 pulse equal to 150 ml)

1.6.9 CAN/S6 output interface specifications and protocol

DFM Marine CCAN output interface specifications correspond to specifications of **S6 Telematics interface**.

DFM Marine CCAN data is sent to S6 bus in automatic transmission mode (basic mode) or by request. Baud rate can be selected out of the following values: 100; 125; 250; 500; 1000 Kbit/s with the help of [Service S6 DFM](#) (default baud rate 250 Kbit/s).

Telematics interface S6 allows connection of up to 8x DFM Marine CCAN fuel flow meters to one input of telematic terminal. Unique decimal addresses (SA) from 111 to 118 should be set for each meter (default address 111).

Table 7 — Messages of DFM Marine CCAN data transfer protocol

Message ID	Short message description
PGN 59904	Request
PGN 62987	Vehicle voltage
PGN 62994	Unit work counters*
PGN 62995	Unit passport*
PGN 63011	Time origin settings*
PGN 63026	Fuel consumption factors*
PGN 63044	Calibration table. Fuel rate*
PGN 63054	CAN settings*
PGN 63055	Important events list*
PGN 63056	Information events list*
PGN 63064	Battery voltage mode borders*
PGN 63086	Battery
PGN 63157	Flowmeter. Engine total hours of operation
PGN 63159	Flowmeter. Parameters
PGN 63160	Flowmeter. Counters*
PGN 63161	High resolution fuel consumption (liquid)
PGN 63162	Average fuel rate
PGN 63163	Borders. Fuel rate*
PGN 63165	Flowmeter characteristics*
PGN 63166	Information display system*
PGN 63167	Flowmeter. Engine total hours of operation (clearable)
PGN 63170	Flowmeter. Engine total hours of operation in idle
PGN 63171	Flowmeter. Engine total hours of operation in optimal mode
PGN 63172	Flowmeter. Engine total hours of operation in overload mode
PGN 63173	Flowmeter. Engine total hours of operation in cheating mode
PGN 63174	Flowmeter. Engine total hours of operation in interference mode
PGN 63196	Differential fuel rate. Params
PGN 63197	Differential fuel rate. Counters
PGN 63198	Differential fuel rate. Engine total hours of operation
PGN 63199	Differential fuel rate. Engine total hours of operation (clearable)
PGN 63200	Differential fuel rate. Engine total hours of operation in idle

















Message ID	Short message description
PGN 63201	Differential fuel rate. Engine total hours of operation in optimal mode
PGN 63202	Differential fuel rate. Engine total hours of operation in overload mode
PGN 63203	Differential fuel rate. Engine total hours of operation in cheating mode
PGN 63204	Differential operation mode*
PGN 63205	Borders. Differential fuel rate*
PGN 63207	Differential fuel rate. Engine total hours of operation in negative mode
PGN 65226	Active diagnostic trouble codes
PGN 65227	Previously active diagnostic trouble codes
PGN 65254	Time/date*
PGN 65262	Engine temperature 1
* On request.	

More details on parameters, structure and contents of DFM Marine CAN communication protocol messages you will find in Database S6 at <http://s6.jv-technoton.com>.

1.7 DFM Marine and tracking devices compatibility

[Technoton](#) regularly conducts tests for compatibility and joint accuracy of [DFM Marine](#) with different models of terminals (vehicle tracking devices) of popular brands. Table 8 shows the models of terminals compatible with DFM Marine providing accuracy of joint measurement of fuel consumption not more than $\pm 1\%$.

Table 8 — Vehicle tracking devices compatible with DFM Marine

Tracking device			Analytical software (tracking platform)
Brand	Name	Model	
	CKPT	31	ORF-MONITOR
		25	
		45	
	GALILEOSKY	GPS	Wialon
		GLONASS	
	Autograf	GSM+	AutoGRAF
		GSM(GLONASS)	
	Teltonika	FM4200	Wialon Hosting
		FM5300	
	Ruptela	FM-Pro3	Trust-Track web server
		FM-Pro4	
	MapOn	GBOX6	MapOn web server
	GLOSAV	BK11-02	GLOSAV
	Locarus	702X	LocarusInformer
		702R	
		702S	
		Locarus 15	Wialon Hosting
	BCE	Fm Light	Wialon
	VOYAGER	2	RITM-PCN
	Simbiotecha	GATE-FM 200	Monitoring server software "Fuel control system" www.tracking.lt
	SKOUT	MT-530	Scout Explorer
		MT-600 GP PRO	
	Naviset	GT-10	GPS-Trace Orange
	NaviFleet	ET100	NaviFleet
	BITREK	BI-910 TREK	Wialon Hosting
	ENTI	NT 110G	R-Drive Operator

Relevant information on the compatibility of specific tracking device and DFM Marine models and recommendations for their connections and settings can be found at www.jv-technoton.com

1.8 DFM Marine selection



IMPORTANT: Final decision on possibility to use particular model of [DFM Marine](#) should be made by installation specialist after inspection of the engine/burner, where flow meter will be installed.

1.8.1 Selection depending on engine power (boiler output capacity)

Table 9 — DFM Marine selection depending on the engine power (boiler output capacity)

Engine power *, kW	Boiler output *, kW	Recommended DFM model
from 1500 to 3600	from 4000 to 10 000	DFM Marine 1000
from 3600 to 7300	from 10 000 to 20 000	DFM Marine 2000
from 7300 to 14 700	from 20 000 to 40 000	DFM Marine 4000
* Data is for reference purpose only. To choose flow meter properly, it is necessary to know maximum and minimum fuel consumption in fuel supply line of fuel consumer.		

1.8.2 Selection depending on fuel flow rate in supply and return lines of the engine

For differential fuel consumption measurement, a pair of [DFM Marine CAN](#), connected through CAN/S6 technology (see [2.6.8](#)). The first flow meter is installed in supply line, the second flow meter in return line. Flowmeters are selected depending on the flow range in the relevant fuel line (see table 10).

Table 10 — Selection of DFM Marine depending on fuel flow rate values in supply and return lines

Minimum flow rate, m ³ /h	Maximum flow rate, m ³ /h	Recommended models
0.2	1	DFM Marine 1000
0.4	2	DFM Marine 2000
0.8	4	DFM Marine 4000

IMPORTANT:



1) Maximum and minimum fuel flow rate values in supply and return lines of the engine can be found in performance specification of the engine fuel pump.

2) Differential measurement on the fuel system with high performance pump and engine with small fuel consumption use not recommended. For example, the booster pump performance is 3 m³/h, fuel consumption in idle run mode is 0.1 m³/h, and relative fuel measurement error in supply and return lines is 1 %, absolute error value of differential measurement is up to 0.06 m³/h. That is comparable with the amount of fuel consumed by the engine.

3) Counter-indication to install a differential fuel flow meter is the fact of air bubbles presence in supply or return fuel lines. A task of removing air from fuel is resolved by installation of **deaeration device (deaerator)**.

2 DFM Marine installation



ATTENTION:

- 1)** To ensure proper operation of DFM Marine, it should be mounted, electrically connected and configured by specialist, who finished official technical training and was certified for that.
- 2)** Officials, who carry out installation and operation, are responsibility for proper installation and operation of DFM Marine from the moment of its purchase.
- 3)** When installing DFM Marine it is obligatory to follow safety rules on carrying out repair works applicable to the machinery being equipped.

This section contains general recommendations on [DFM Marine](#) mounting.

2.1 Exterior inspection prior to works start

It is required to conduct DFM Marine exterior inspection for the presence of the possible defects arisen during transportation, storage or careless use:

- visible damages of the meter body, fittings, bracket, display, interface cable and connector;
- backlash of component parts or gaps between them.

Contact the supplier if any defects detected.

2.2 Estimation of the fuel consumer condition



IMPORTANT:

- 1)** Before starting installation of [DFM Marine](#), carefully read technical specification of the machinery unit being equipped, inspect the condition of its fuel and electric systems and make a conclusion whether it's possible to make installation of the flow meter.
- 2)** Make sure, that specifications of fuel system are within a range of main flow meter specification (kinematics viscosity of the liquid, consumption rate, pressure, operating temperature, nominal bore (DN)).

Machinery condition inspection is carried out according to the following sequence:

- 1)** Start the engine and check its operation for 5-10 minutes at idle and 5-10 minutes in movement under load. The engine must run evenly, not stall under load, loss of power must not be felt.
- 2)** Check the return flow of the injectors. In case of significant return flow of the injectors measurement accuracy error will get higher because this returned volume gets back to tank and is double-counted by DFM Marine. Injectors maintenance is recommended prior to DFM Marine installation in this case.
- 3)** Check pressure in the fuel line with a pressure gauge. Hydraulic resistance of a selected DFM Marine working at nominal flow rate should not lower the pressure by more than 5 %.
- 4)** Inspect all fuel pipes of the vehicle for damage and fuel leakage.
- 5)** Check the quality of the chassis ground of the vehicle. Resistance between any point of chassis and the "-" clamp of the battery should not exceed 1 Ohm.
- 6)** Check electric system voltage with a voltmeter. 12 V onboard power system should have voltage in the range from 10 to 18 V. 24 V onboard power system should have voltage in the range from 18 to 32 V.
- 7)** Check and eliminate any external electromagnetic interference at the place of installation

According to the results of the check a **Protocol of inspecting machinery unit** should be filled in and signed (see [annex B](#)).

The customer should eliminate any malfunctions recorded to the report before DFM Marine installation.

2.3 General installation instructions

**IMPORTANT:**

- 1) Installation and electrical connection of [DFM Marine](#) is strongly recommended at a positive ambient temperature.
- 2) For proper selection of installation place, carefully read technical documentation for the machinery unit.


The following is needed for DFM Marine mounting:

- hand tools (spanner and socket wrench sets, screwdrivers);
- mounting kit including bolt and flange connectors, O-rings, mounting consumables – appropriate materials are purchased separately for each particular installation case, taking in account type and size of fuel tubes, installation and operation conditions;
- pyrometer or contact thermometer (ordered separately);
- glycerin filled manometer (ordered separately);
- mud filter (purchased separately).

The following rules must be observed when DFM Marine mounting:

- 1) Fuel flow meter should be installed in an easy accessible place, reachable for data reading from display and technical maintenance of the device.
- 2) Before installation, smoothly close shut-off valves and using a manometer make sure that there is no pressure inside the fuel line.
- 3) Prepare fuel tubes and flow meter installation place, taking in account its dimensions. Use additional intermediate element for fuel line, if necessary.
- 4) To ensure declared accuracy of measurement, it is allowed to install fuel flow meter **in "head up" position only**. Flow meter can be slightly (up to 30 degrees) inclined up or down from its horizontal axis. **Installation of flow meter heading down is not allowed** (see figure 15).

Correct






Figure 15 — DFM Marine operating position relatively to vertical and horizontal planes

- 5) To protect measurement chamber of flow meter from damage, it is necessary to install rough filter in the fuel line before [DFM Marine](#) (see figure 16).

It is not allowed to install DFM Marine without installing mud filter before it.

If fuel contains mud, it is recommended to use rough filter with magnetic elements.

Maximum width of rough filter cells is: 0.250 mm (for DFM Marine 1000) and 0.400 mm (for DFM Marine 2000 and DFM Marine 4000).



a) with flange connection



b) with thread connection

Figure 16 — Rough filter examples

- 6) Tightening forces of threaded connections when installing flow meter is:
- for M6 thread – 6 N·m;
 - for M8 thread – 16 N·m;
 - for M12 thread – 47 N·m.
- 7) **DFM Marine should be installed in a way, that provides fuel flow inside the fuel line will be in the same direction, as the pointing arrow on the body of DFM Marine.**


For proper operation of measuring chamber of DFM Marine, it is not obligatory to have straight fuel line sections before and after the flow meter.

When connecting flow meter to the fuel line, make sure that flanges and threads clean of mud and dirt.

Use new tightening materials (washers and gaskets) only.

When installing DFM Marine with thread connection it is recommended to use **mounting plate** of metal (see [annex H](#)). Mounting holes on DFM Marine body are described in [annex A](#).

Flanges and threads should be connected precisely, without excessive effort, also make sure they are not skewed (see figure 17).



a) with flange connection

b) with thread connection

c) skewed fuel line

Figure 17 — Flow meter installation in fuel line

- 8) After DFM Marine installation make sure that fuel system is tight and let air out of it. Measuring chamber of flow meter should always contain fuel without air in it.
- 9) Maximum allowed pressure drop after the flow meter is less than 3 bars. If a pressure drop after the fuel flow meter is more than 1 bar, it is recommended to select DFM Marine of bigger size, which has bigger nominal bore (DN).
- 10) To avoid water hammers (hydraulic shocks) in fuel line, valves should be opened and closed smoothly.

ATTENTION:



- 1) To measure fuel consumption, it is necessary that only the volume of fuel consumed by the engine flows through the [DFM Marine](#). To guarantee that, modification of fuel line might be necessary. When modifying fuel line, use standard or identical tubes applicable for this piece of machinery.
- 2) To avoid exceeding upper boundary of operating temperature range of DFM Marine, measuring head of installed flow meter should be isolated from heat sources.
- 3) If you spot foam or air bubbles in return fuel line of the machinery, it is necessary to additionally install de-aeration system.

2.4 Example schemes of flow meter installation into fuel line

1) Using shut-off return valve

One of the features of diesel engines is its uneven fuel consumption. Additionally, water hammers (hydraulic shocks) inside fuel line can add extra inaccuracy. To compensate water hammer effects and to avoid back fuel flow through DFM Marine, it is necessary to install **return valve** after the flow meter (see figure 18).





Figure 18 — Using shut-off return valve to increase accuracy and protect DFM Marine against water hammers

2) Additional details for installation on vessels and locomotives


When installing [DFM Marine](#) on vessels and locomotives it is very important that fuel supply will be uninterruptable in case of hard clogging of mud filter or during flow meter maintenance. So, **it is necessary to ensure temporary redirection of fuel supply through additional bypass fuel tubes.**

When pressure in fuel line drops below specific value, pneumatic switch cuts off fuel supply through main tube and automatically opens electromagnetic valve on bypass tube. From this point, fuel is supplied through bypass tube in full amount, but without consumption measurement. If you see air bubbles in fuel going through supply and/or return line, it is recommended to connect both lines through intermediate fuel tanks to de-aerate the fuel (see figure 19).

If one machinery unit has several engines, you will need to install DFM Marine to fuel supply system of each engine.



a) standard scheme



b) scheme with intermediate tank

Figure 19 — Examples of DFM Marine installations schemes for vessels, using automatic fuel supply redirection through bypass tube

3) Flow meter installation on suction side

[DFM Marine](#) installation on suction side of fuel system assumes that fuel flow meter will be installed before fuel pump, where fuel flows due to underpressure created by pump. To implement scheme of installation on suction side, it might be necessary to modify return line of fuel system.




Figure 20 — Example of DFM Marine installation on suction side, using bypass tube

4) Flow meter installation on pressure side

DFM Marine installation on pressure side assumes, that flow meter will be installed in fuel system after the pump, where fuel flows due to pressure created by pump. To implement scheme of installation on pressure side, it might be necessary to modify return line of fuel system.




Figure 21 — Example of DFM Marine installation on pressure side, using bypass tube

5) DFM Marine installation according to "Differential" and "Summarization" schemes.

ATTENTION:



1) to use "Differential" and "Summarization" installation schemes you will need to use a pair of **DFM Marine CAN** flow meters, which are connected with each other using S6 Technology (see [2.6.8](#)).

2) It is allowed to use a pair of flow meters which have different fuel flow rates (e.g. DFM Marine 4000 for supply line and DFM Marine 2000 for return line).

When using "Differential" installation scheme, fuel circulation in fuel system is not changed. The first flow meter (Master) is installed in supply line, the second flow meter (Slave) in return line. Differential consumption is defined as difference between measurements of those two DFM Marine CAN flow meters (see figure 22 a).



RECOMMENDATION: Do not use "Differential" scheme if fuel pump capacity is much higher than fuel consumption by engine. In this case the inaccuracy could be higher than acceptable.

DFM Marine CAN fuel flow meters can be also used to summarize consumption of fuel, which goes through two lines (e.g. when stationary tank is refilled). First flow meter (Master) is installed in line #1, second flow meter (Slave) is installed in line #2. Summarized fuel consumption is defined by aggregation of fuel consumption data from both DFM Marine CAN flow meters (see figure 22 b).




Figure 22 — Examples of schemes when a pair of DFM Marine is installed

6) Fuel line ventilation scheme

When cleaning fuel line from mud/dirt with air, it is necessary to ensure that the air will not go through measuring chamber of the flow meter. Before using air, close shut-off valves before and after [DFM Marine](#). After cleaning the tubes, rinse valves with fuel to remove small pieces of dirt.




Figure 23 — Scheme of cleaning fuel tubes with air

7) Fuel dispensing scheme

When dispensing fuel, the valve is installed between flow meter and fuel line outlet. Short segment of fuel line between valve and outlet will provide higher accuracy. Taking in account possible water hammers, open and close valves smoothly.




Figure 24 — Fuel dispensing scheme

2.5 Electrical connection



ATTENTION:

- 1) To ensure proper operation of [DFM Marine](#), it should be electrically connected by specialist, who finished official technical training and was certified for that.
- 2) When installing DFM Marine it is obligatory to follow safety rules on carrying out repair works applicable to the machinery being equipped.

Fuel flow meters with interface cable (**DFM Marine CK/CCAN**) are supplied with electrical power from onboard vehicle power source

IMPORTANT:



- 1) Before mounting and connecting DFM Marine switch off power supply of the [Vehicle](#) electrical circuits. To do this switch off the battery switch or release the terminals of the wires connected to the battery.
- 2) It is recommended to use **fuses** (supplied within delivery set) when connecting DFM Marine power supply. Nominal fuse current is not more than 2 A.
- 3) When connecting DFM Marine to onboard power source it is necessary to connect feed "+" and chassis "-" wires to the same sockets where appropriate wires of recording and display devices (trackers) are connected.
- 4) Before starting electrical connection of the sensor special attention must be paid to the quality of the chassis ground. Resistance between any point of the chassis and the negative clamp of the battery must not exceed 1 Ohm.
- 5) It is **strongly recommended** to lay DFM connection cable together with standard electrical vehicle wiring with mandatory cable ties fixing of every 50 cm, at a positive ambient temperature (see figure 25).




Figure 25 — Laying DFM Marine signal cable

Electrical connection of DFM Marine is carried out by connecting **signal cables** (see [annex D](#)) in accordance with pinout and wires designation (see table 12 and 13).

Quick splice connectors (ordered separately) are recommended for electrical connection of power supply wires (see figure 26).

Table 11 — Cables for electrical connection of [DFM Marine](#) with interface cable

View	Component name	Description
	S6 SC-CW-700 (signal cable) (see annex D)	Designed to connect DFM Marine CAN to recording and display devices and to external power supply. 7 meters long. Not included into delivery set. Equipped with 2 terminating resistors (120 Ohm).
	CABLE DFM 98.20.003 (signal cable) (see annex D)	Used for DFM Marine CK flow meter with pulse output interface connection to telematic terminal (or data logger) and on-board power supply network. Length - 7,5 m. The cable is included in delivery set of DFM Marine CK with pulse output interface.




Figure 26 — Wiring connection made with the plastic connectors

Table 12 — Interface cable pinout and wire assignment of DFM Marine CK






Connector view	Pin number	Wire color		Assignment
	1	Orange		Power supply “+”
	2	Brown		Ground
	4	White		Pulse output (see 1.6.8)
	5	Black		K-Line (ISO 14230)

Table 13 — Interface cable pinout and wire assignment of DFM Marine CCAN

Connector view	Pin number	Wire color		Assignment
	1	Orange		Power supply “+”
	2	Brown		Ground
	3	Blue		CAN-High (SAE J1939)
	4	White		CAN-Low (SAE J1939)
	5	Black		K-Line (ISO 14230)

Check [annex E](#) for DFM Marine CCAN and tracking devices connection options and required connection cables models.

2.6 Fuel flow meters configuration

All [DFM Marine](#) fuel flow meters are calibrated and verified by the manufacturer with a diesel fuel and supplied ready for use.

When DFM Marine with interface cable (**DFM Marine CK/CCAN**) is connected to external device or it is necessary to adjust DFM Marine parameters to specific operation mode, you can configure it through K-line interface (ISO 14230).

In order to start configuration, it is necessary to connect DFM to PC via SK DFM or S6 SK service adapters. SK DFM description can be found in [DFM fuel flow meters operation manual v.5.0](#). S6 SK description can be found in [Cabling and accessories for Telematics interface S6 manual](#).

Before connecting DFM Marine to PC via service adapter, please download the USB driver and software Service DFM Marine from <http://www.jv-technoton.com> (section [Software/Firmware](#)) and install it to your PC. Installation file name contains: Service_DFM_Marine_X_X_Setup.exe, where X_X — version of software.

2.6.1 Connecting DFM Marine to PC



ATTENTION: To avoid any service adapter faults in communication between PC and fuel flow meter make sure there are no sources of electromagnetic interference close to the workplace (running electric motors, welding equipment, high-power transformers, power lines, etc.).

Before starting to use service adapter, have a closer look on its elements to detect defects which can occur while service adapter was transported, stored or handled carelessly.

When connecting service adapter to DFM Marine, which is installed on vehicle, avoid the following: ingress of fuel, oil or moisture to the pins of connector; damage of elements by rotating or heated parts of engine/vehicle.



ATTENTION: Power down the electrical system of the vehicle prior to DFM Marine connecting to the PC. Use the battery switch or take off the battery contact terminals.

DFM Marine meters are connected to PC according to the connection schemes (see figure 27) in the following order:

1) Connect the adapter to flow meter


When configuring DFM Marine within Telematics interface S6 the connector of CAN service cable (applicable for SK DFM) or service cable (applicable for S6 SK) is connected to an appropriate free S6 input. Flow meter and adapter power supply is done through S6 cabling system (see figures 27 a, b);

When configuring DFM Marine not within Telematics interface S6 the connector of CAN service cable (applicable for SK DFM) or service cable (applicable for S6 SK) is connected through coupler (supplied with S6 SK) to DFM Marine output interface cable. Flow meter and adapter power supply is connected through one of free connectors of the coupler (see figures 27 c, d)


- 2) Connect the adapter with USB cable (applicable for S6 SK) or USB A-B cable (applicable for SK DFM) to a free USB-port of your PC.
Adapter can also be connected to USB-port of your PC after turning Vehicle's electrical system ON and starting the software.
- 3) Connect power wires to on-board electrical system or to an external power supply unit.
- 4) Turn Vehicle's electrical system ON.




a) while using S6 SK for configuration of DFM Marine within S6 Telematics interface



b) while using SK DFM for configuration of DFM Marine within S6 Telematics interface



c) while using S6 SK for configuration of DFM Marine out of S6 Telematics interface



d) while using SK DFM for configuration of DFM Marine out of S6 Telematics interface


Figure 27 — DFM Marine to PC wiring schemes

Windows automatically detects adapter connected to PC's USB port as USB device and enables virtual COM port driver for it. The virtual COM port will be displayed in the list of ports of Windows Device manager (see figure 28 a).




ATTENTION: to work with Service DFM Marine it is recommended:

- 1) It is recommended to use the same USB port of the PC for adapter connections.
- 2) Untick power save check box in virtual COM-port properties (see figure 28 b).



a) selecting port properties






b) disabling power save option

Figure 28 — Virtual COM-port configuration in Device manager

Adapter is ready for operation straight after power supply connection. Check for a description of blinking LED-indicators placed on the top of the adapter in table 14.

Table 14 — Description of adapter's LEDs

LED Indicator				Signal description
Marking		Status	Light color	
for S6 SK adapter	for SK DFM adapter			
POWER	ON		Red	Power supply is on
		No signal		Power supply is off (or voltage is less than minimum required)
RX			Green	DFM Marine data is being received
		No signal		No data from DFM Marine
TX			Yellow	Data is being transmitted to DFM Marine
		No signal		No data to DFM Marine

2.6.2 User interface

Service DFM Marine is launched with a  label which is created during the installation process. Service DFM Marine user interface consists of **Horizontal menu**, **Vertical menu**, **Flow meter's ID area** and **Information and configuration area** (see figure 29).




Figure 29 — Service DFM Marine software interface

Flow meter's ID area displays data on model, serial number, production date and firmware version of the connected meter.

Horizontal menu provides following options:


- connection/disconnection of the flow meter;
- meter profile options (loading profile, saving profile, printing profile);
- updating firmware of the meter;
- selection of interface language;
- viewing help file and information about the utility.


Vertical menu is used for selection of [Functional modules](#) (hereinafter FM) of the meter. The actual parameters of FM and settings are displayed at **Information and configuration area**.

Connectivity of software with FM is based on [PGNs](#) and [SPNs](#) ([S6 Database](#)) exchange. SPNs of DFM Marine Functional Module which are read and/or edited in **Information and configuration area** are listed in [annex F](#).


Vertical menu also contains entries on real-time diagnostics of measuring chambers and events records.

2.6.3 User authorization

To establish connection with [DFM Marine](#) push  at **Horizontal menu**. Service DFM Marine will run a search of connected meters (see figure 30 a).

Note — When connecting adapter to S6 Telematics interface which has more than one DFM Marine CAN select the required flow meter out of the list in **Connection** window and push  button (see figure 30 b).

Enter installer's login and password in the fields of **Authorization** window. Default login is 0. Default 1111. Tick **Remember password** checkbox to save the password for further launches (see figure 30 c).



a) search of connected meters b) selecting one of several Units connected to S6 bus c) user authorization

Figure 30 — Establishing connection between PC and DFM Marine

For password recovery (if it was lost) press Ctrl+F10 in the password field of **Authorization**. Service DFM Marine will generate restore code (see figure 31). Send the restore code to Technoton support via e-mail support@technoton.by together with recovery request.

Requirements for password recovery request:

- scan copy of the request signed and sealed by the official representative of the company the flow meter been purchased by should be attached;
- request should contain serial number of the meter;
- email should contain full name and contact e-mail of a person who should receive the recovered password.





Figure 31 — Generated recovery code window

In case of entering incorrect login/password or in case of wrong connection to PC the software will show an error message.

In case of successful authorization with login and password the software will automatically prompt **Desktop** window (see figure 29), which displays currently connected DFM's configurations and parameter values of [Functional modules](#).

2.6.4 Working with DFM profile

Profile of [DFM Marine](#) is represented by a set of [PGNs](#) (specifications, counters and configuration of [Functional modules](#) of DFM Marine).

For managing DFM profiles in both meter connected mode and autonomous mode  button with drop-down list is used (see figure 32). This button is placed at **Horizontal menu** of Service S6 DFM. Profile can be stored as a file to PC hard drive or loaded into the memory of the meter. It can be printed as well.





Figure 32 — Profile menu

 menu has following entries:

1) Load profile. Service DFM Marine has following options of flow meter profile load:

- [Load from file](#) — for loading of previously saved profile from the hard drive or removable disk. Select the **DFM_*.prf** file of the flow meter profile in the appeared Open window.
- [Load from Unit](#) — used for loading profile from the connected flow meter.



ATTENTION: When there is an active connection between DFM Marine and PC it is possible to load profile from file of only the same interface as connected [Unit](#). Otherwise the warning message will appear (see figure 33).




Figure 33 — Warning on interfaces incompatibility of profiles of loaded and connected Unit

- [Load default profile](#) — is used for loading profile with default factory settings. With this profile it is possible to study utility operation without real DFM Marine connection. Default profile is stored in **DFM_*_default.prf** file in the folder of Service DFM Marine.



ATTENTION: In autonomous mode only, default profile or previously saved profile is available for loading.

* **CAN** (for DFM Marine with CAN/S6 interface) or **K** (for DFM Marine with pulse output).

2) Saving profile. Service DFM Marine has following profile saving options:

- Save to file — for saving profile to the hard drive or removable disk. This option is available only for profile loaded from file or [Unit](#).



Select the location and give a name to file according to format **DFM_*.prf**.

Enter a name instead of an asterisk in the template. The prefix **DFM_** and the extension **.prf** will be inserted automatically.



ATTENTION: Saved profile then can be loaded only when DFM with the corresponding output interface is connected.

- Save to Unit — is used for saving modified settings into profile of the connected [DFM Marine](#). It is available only during the time when there is an active connection between PC and DFM Marine.

If the modified settings were not saved into Unit and  button was pressed or Service DFM Marine window is being closed there will appear a notification. Pressing  will save all the unsaved parameters and settings into DFM Marine.

3) Print profile. This window allows selection of the printer and printing settings.

The printed copy will contain flow meter profile data as well as the date when it been printed.



RECOMMENDATION: It is recommended to attach the hardcopy of the profile to the meter's specification to log the history of the settings and configurations.

2.6.5 Configuration for connection to external terminal unit

Fuel flow meters with pulse output interface (**DFM Marine CK**) does not require any output signal configuration.

Fuel flow meters with pulse digital interface (**DFM Marine CCAN**) require output signal configuration to be connected to external terminal unit. Go to **Interface** to configure output signal parameters:

- 1) From the drop-down menu of **Protocol** list choose required data transfer protocol. For DFM Marine CAN — **SAE 1939+S6** or **NMEA 2000**.
- 2) To unit identification within [S6](#), enter unique network address of DFM Marine CAN from a range 1101...118 (by default – **111**) to **Address in S6 bus (SA)** field
- 3) From the drop-down menu of **Data transfer rate** list choose data transfer speed: for CAN interface you can choose one of the following data transfer speeds: 100; 125; 250; 500; 1000 Kb/s (by default— 250 Kb/s).



ATTENTION: Parameters modified in **Desktop** window are automatically modified in corresponding windows of FM setting entries and vice versa

2.6.6 Operation check


In order to check operation of installed fuel flow meter go to **Charts** menu of the Software where live data is displayed (see figure 34):

- for one flowmeter:
 - chart of hourly (instant) consumption of fuel, which went through the only measuring chamber (blue line) ([SPN 521313](#));
 - current Counter values — Total fuel consumption ([SPN 521314](#)) and fuel consumption in "Tampering" mode ([SPN 521314/9.3](#)).
- for differential measurement:
 - blue chart line of hourly (instant) consumption of fuel, which goes through measuring chamber of "Master"-flowmeter ([SPN 521313](#)), installed in fuel supply line. Additionally, green chart line of differential consumption of fuel, which goes through "Master" and "Slave" flow meters ([SPN 521313/2.15](#)) (see [2.6.8](#)).
 - Current Counters values — Total fuel consumption ([SPN 521314/2.15](#)) and fuel consumption in "Tampering" mode ([SPN 521314/2.15/9.3](#)).

Horizontal pink dotted lines display configured boundaries of operation modes (see [1.6.5](#)). You can change configuration of operation modes boundaries in **Desktop** or **Flowmeter Marine FM** window (see [annex F](#), Flowmeter Marine FM).



a) chart example of one flow meter



b) char example of differential measurement

Figure 34 — DFM Marine operation test with Charts window

2.6.7 Configuration for specific operation conditions

In order to get better accuracy for specific conditions of operation, you can change the following settings through the Software (**Flowmeter Marine FM** or **Desktop** window):

1) Set up boundaries of operation modes of DFM Marine (in **Borders. Fuel Rate** area), which are used to define current workload of Vehicle depending on its hourly consumption rate ([PGN 63163](#)):

- "Idle" – workload less than 10 % of maximal hourly consumption rate;
- "Optimal" – workload 10 to 75 % of maximal hourly consumption rate;
- "Overload" – workload 75 to 100 % of maximal hourly consumption rate.

In one-chamber flow meters a user can adjust only "Idle" ([SPN 521317/9.0](#)) and «Optimal» ([SPN 521317/9.1](#)) modes. Factory-set configuration for "Overload" mode ([SPN 521317/9.2](#)) could not be adjusted.

2) Turn on temperature correction function, i.e. automatic correction of fuel volume consumption data adjusted to fuel temperature ([SPN 521311](#)).

Temperature correction function is used because volume of fuel changes when fuel temperature is going up/down.

After turning on temperature correction function a user can enter temperature correction coefficient of volumetric expansion (coefficient of volumetric expansion of oil products β in relation to temperature change by 1 °C) ([SPN 521433](#)).

β coefficient value should be chosen from table 15, taking in account density ρ of oil product at the temperature of plus 20 °C.

3) Configure consumption correction factor ([SPN 521434](#)). This parameter allows increasing accuracy of fuel consumption measurement if a user constantly detects derivation (values are too high/low) of measured consumption related to specific conditions of operation (increased vibration of Vehicle, air presence in fuel lines, higher fuel flow in reverse line of nozzles).

For example, if fuel flow meter shows 3 % higher results of measurement, it is necessary to enter consumption correction coefficient equal minus 3 %. If fuel flow meter shows 2 % lower results of measurement, it is necessary to enter consumption correction coefficient equal plus 2 %.

4) System of units (Metric or American) for displaying measurement results on flowmeter's display ([SPN 521332](#)).

Table 15 — Selection of oil products volumetric expansion coefficient

ρ , kg/m ³	β , 1/°C	ρ , kg/m ³	β , 1/°C
690.0 - 699.9	0.00130	850.0 - 859.9	0.00081
700.0 - 709.9	0.00126	860.0 - 869.9	0.00079
710.0 - 719.9	0.00123	870.0 - 879.9	0.00076
720.0 - 729.9	0.00119	880.0 - 889.9	0.00074
730.0 - 739.9	0.00116	890.0 - 899.9	0.00072
740.0 - 749.9	0.00113	900.0 - 909.9	0.00070
750.0 - 759.9	0.00109	910.0 - 919.9	0.00067
760.0 - 769.9	0.00106	920.0 - 929.9	0.00065
770.0 - 779.9	0.00103	930.0 - 939.9	0.00063
780.0 - 789.9	0.00100	940.0 - 949.9	0.00061
790.0 - 799.9	0.00097	950.0 - 959.9	0.00059
800.0 - 809.9	0.00094	960.0 - 969.9	0.00057
810.0 - 819.9	0.00092	970.0 - 979.9	0.00055
820.0 - 829.9	0.00089	980.0 - 989.9	0.00053
830.0 - 839.9	0.00086	990.0 - 999.9	0.00052
840.0 - 849.9	0.00084	—	—

2.6.8 Differential/summarization operation mode



ATTENTION: To operate in Differential and Summarization modes a pair of [DFM Marine](#) connected via [S6 Telematics interface](#) is used (see [annex E](#), figures E.2 and E.4).
A network address from 111...118 range should be attached to each flow meter (see [2.6.5](#)).

Flowmeter configuration is carried out in **FM Flowmeter Marine** window in the following sequence (see [annex F](#)):

1) In **Calculation Mode** dropdown list enable mode of counting DFM Marine CAN ([SPN 521270](#)):

- **Differential** – fuel consumption is calculated as a difference between fuel consumption measured by flowmeter in supply and return lines (see [2.4](#), figure 22 a);
- **Summing** – fuel consumption is calculated as a sum of fuel consumption measured by flowmeter in first and second fuel lines (see [2.4](#), figure 22 b).

2) In **Master Mode** dropdown list enable Master mode for primary flowmeter and disable for secondary flowmeter ([SPN 521268](#)).



ATTENTION: for differential measurement a Master is a flow meter, which is installed in fuel supply line, Slave is a flowmeter installed in return fuel line.
In summarization mode, primary and secondary roles of flowmeters are assigned arbitrary.

3) Enter a unique network address in **Slave Device Address** field for Slave-flowmeter ([SPN 521269](#)). Elected address should not be the same as Master-flowmeter has.

4) In **Borders. Differential Fuel Rate** area, define values for differential instant fuel consumption range ([PGN 63205](#)) (similar to **Borders. Fuel Rate** configuration, see [2.6.7](#))

5) If necessary, enter **Differential Fuel Rate Correction Coefficient** ([SPN 521271](#)) for Master-flowmeter to increase accuracy of measurement (similar to **Consumption correction factor** configuration, see [2.6.7](#))



IMPORTANT: To operate in Differential and Summarization modes power supply voltage of flowmeters should not drop out of 10...45 V range.

3 Measurement accuracy check



ATTENTION: To determine measurements accuracy of [DFM Marine](#) flow fuel meter mounted on the vehicle it is required to carry out a test.

Measurement accuracy check is an obligatory procedure, which defines relative inaccuracy of fuel consumption measurement on equipped [Vehicle](#).

3.1 Test conditions

Tests must be conducted in presence and under control of representatives of all interested parties.

Only people who have studied DFM Marine and recording devices operational documentation and who have experience with testing equipment are allowed to conduct the tests.

Install the DFM Marine fuel flow meter and connect it to recording and display devices. Conduct all works in accordance with the installation manuals for fuel flow meters and recording and display devices.

Conditions of the test:

- tests are conducted on properly operating (fault-free) Vehicles. Before starting the test, remove air from the fuel system and warm up the engine to operating temperature;
- fuel must not contain any mud or other impurities;
- the engine must run at medium speed (RPM);
- duration of the tests — before the engine is produced at least 10% of the volume of the standard fuel tank, but not less than 1 hour;
- engine shutdown is not allowed during the test;
- to measure the volume of fuel in tank during the tests, it is necessary to use the certified measuring instruments (measuring ruler or a measuring capacitance).

3.2 Conducting the tests

[DFM Marine](#) measurement accuracy check sequence:

- 1) Measure precise volume of fuel, which is contained in fuel tank on the beginning of procedure (V_{initial}).
- 2) Start the engine and set the average speed.
- 3) Record the time when the test was started.
- 4) Write down starting value of fuel consumption from DFM Marine screen (V_0).
- 5) Let engine consume at least 10 % of tank volume, while engine running time should not be less than 1 hour.
- 6) Stop the engine.
- 7) Measure volume of fuel remaining in tank (V_{remain}).
- 8) Write down final value of fuel consumption (V_1) from DFM Marine screen.
- 9) Calculate **real fuel consumption** ($V_m = V_{\text{initial}} - V_{\text{remain}}$).
- 10) By difference of initial (V_0) and final (V_1) DFM Marine readings determine **measured fuel consumption** ($V_{\text{measured}} = V_1 - V_0$).
- 11) Calculate the **relative measurement error of fuel consumption** by the formula:

$$\delta = \frac{V_{\text{measured}} - V_m}{V_m} \cdot 100\%$$

where V_{measured} – measured fuel consumption, m^3 ;
 V_m – actual fuel consumption, m^3 .

- 12) Record the result into the protocol. See [annex C](#) for protocol template.




Figure 35 — Example of a fuel system diagram for measurement accuracy check



IMPORTANT: When carrying out accuracy test of [DFM Marine](#) flow meter, you can use the values from "Total fuel consumption" Counter (see [annex F](#), Flowmeter FM), at the same time: **keep in mind**, that there is a 12 s time lag in DFM Marine with display between the moment when values appearing on the display of flow meter and sent to output interface of flow meter.

4 Registered Events control

Upper area of **Events** window displays a list of the latest **Important Events** and lower area displays a list of **Information Events** registered by [DFM Marine](#) and saved in its internal memory (see figure 36).

1) Important Events:

- flow meter tampering (indicating total tampered volume);
- interference in flow meter operation (indicating total interference time);
- low level of supply voltage (indicating voltage value);
- high level of supply voltage (indicating voltage value).

2) Information Events:

- ignition switched ON;
- ignition switched OFF.

Max 15 events are displayed for each of the lists. Each event has an indication of event name, date and time of occurrence and additional info (if there any).

Events are displayed in chronological order starting with the oldest. Upon reaching the maximum number of displayed events new events overwrite the previous ones.





Figure 36 — Browsing through Events registered by DFM Marine

You can delete all registered Event from DFM by clicking . Important Events cannot be deleted by use.

5 Diagnostics and troubleshooting

Contact your [DFM Marine](#) supplier in case of malfunction.

DFM repair works can be carried out only by certified [Regional Service Centers](#) (RSC). Full list of service centers can be found at www.jv-technoton.com

Limited troubleshooting may be self-conducted (see table 23).

Table 23 — DFM Marine malfunctions, which can be removed without full dismounting of the device

Malfunction	Model	Possible cause	Troubleshooting
No output signal	DFM Marine CK/CCAN	Incorrect connection	Check DFM Marine connection to the tracking device/data logger
		Fuel filter clogging	Remove and clean the fuel filter
Fuel does not flow through the meter	DFM Marine C/CK/CCAN	Fuel filter clogging	Remove and clean the fuel filter
Fuel consumption readings are higher than real consumption rate		Wrong fuel flow meter model selection or error in the mounting scheme	Study the technical documentation of the engine and check the mounting scheme
		Hydraulic shocks in the fuel system	Install a non-return valve into the fuel line on the meter's outlet side. Check valve's operational performance in case it is already installed.

6 Verification

At product release each [DFM Marine](#) flow meter passes departmental metrological verification on metrologically certified automated test rigs.

Verification certificate confirming DFM Marine metrological verification is included into delivery set of each flow meter.

7 Maintenance

To ensure measurement accuracy it is recommended to re-calibrate [DFM Marine](#). Re-calibration interval is defined by increase of "Total Fuel Used" [Counter](#) ([SPN 521314](#)) since previous calibration and equal to:

- for DFM Marine 1000 — 1200 m³;
- for DFM Marine 2000 — 2800 m³;
- for DFM Marine 4000 — 5250 m³.



IMPORTANT: Re-calibration with subsequent verification of flow meters is done in [Regional Service Centers](#) (RSC).

It is recommended to perform visual inspection and DFM Marine operation check at least once a year. In order to provide DFM Marine operability, it is recommended to remove and clean the mud filter from time to time.



IMPORTANT: When you remount DFM Marine, replace used copper washers with new ones.

8 Packaging

[DFM Marine](#) delivery set is supplied in a plywood box, which has labels attached on both sides. Label sticker with information on the product name, certificates, serial number, firmware version, manufacture date, weight as well as Quality Control seal and QR code is stuck on two sides of the DFM Marine box.

9 Storage

[DFM Marine](#) is recommended to be stored in dry enclosed areas.

DFM Marine storage is allowed only in original packaging at temperature range from -50 to +40° C and relative humidity up to 100 % at 25° C.

Do not store DFM Marine in the same room with substances that cause metal corrosion and/or contain aggressive impurities.

DFM Marine shelf life must not exceed 24 months.

10 Transportation

Transportation of [DFM Marine](#) is recommended in closed transport that provides protection from mechanical damage and precipitation.

When transporting by air, DFM Marine must be stored in heated pressurized compartments.

Air environment in transportation compartments should not contain acid, alkaline and other aggressive impurities.

Shipping containers with packed DFM Marine should be sealed.

11 Utilization/re-cycling

[DFM Marine](#) does not contain harmful substances and ingredients that are dangerous to human health and environment during and after the end of life and recycling.

DFM Marine does not contain precious metals in amount that should be recorded.

Contacts

Distribution, technical support and service



Tel/fax: +375 17 240-39-73

info@jv-technoton.com

support@technoton.by



Manufacturer

[Zavod Flometr](#)

Tel/fax: +375 1771 3-99-89

office@flowmeter.by



Annex A

Overall dimensions and weight




Figure A.1 — DFM Marine overall dimensions

Table A.1— DFM Marine overall dimensions

Model	Type of connection	L, inch	F, mm	R, mm	L, mm	B, mm	H, mm
DFM Marine 1000	thread	G3/4	-	-	172	102	117
	flange	-	Ø65	Ø14 (4 hole)	200		
DFM Marine 2000	thread	G1	-	-	194	120	123
	flange	-	Ø75	Ø14 (4 hole)	214		
DFM Marine 4000	thread	G1 1/4	-	-	216	140	141
	flange	-	Ø85	Ø14 (4 hole)	232		




Figure A.2 — Mounting holes placement scheme

Table A.2— DFM Marine weight

Model	Weight, kg, not more than
DFM Marine 1000C FA	2.4
DFM Marine 1000C TA	1.8
DFM Marine 1000C FL	4.8
DFM Marine 1000C TL	3.2
DFM Marine 1000CK FA	2.5
DFM Marine 1000CK TA	1.9
DFM Marine 1000CK FL	4.9
DFM Marine 1000CK TL	3.3
DFM Marine 1000CCAN FA	2.5
DFM Marine 1000CCAN TA	1.9
DFM Marine 1000CCAN FL	4.9
DFM Marine 1000CCAN TL	3.3
DFM Marine 2000C FA	3.3
DFM Marine 2000C TA	2.7
DFM Marine 2000C FL	6.5
DFM Marine 2000C TL	4.5
DFM Marine 2000CK FA	3.4
DFM Marine 2000CK TA	2.8
DFM Marine 2000CK TL	6.6
DFM Marine 2000CCAN FA	4.5
DFM Marine 2000CCAN TA	3.4
DFM Marine 2000CCAN FL	2.8
DFM Marine 2000CCAN TL	6.6
DFM Marine 4000C FA	5.0
DFM Marine 4000C TA	4.3
DFM Marine 4000C FL	9.5
DFM Marine 4000C TL	7.2
DFM Marine 4000CK FA	5.1
DFM Marine 4000CK TA	4.4
DFM Marine 4000CK FL	9.6
DFM Marine 4000CK TL	7.3
DFM Marine 4000CCAN FA	5.1
DFM Marine 4000CCAN TA	4.4
DFM Marine 4000CCAN FL	9.6
DFM Marine 4000CCAN TL	7.3

Annex B

Protocol of inspecting machinery unit

_____/_____/20_____
Date Month Year

We, the undersigned representatives of the Customer

_____,
and representatives of the Contractor

_____,
have conducted vehicle (installation) inspection

Vehicle type _____

Brand, model _____

Registration number _____

for conformity to DFM Marine installation requirements, and have concluded the following:

Requirement	Conforms/ Does not conform	Notes
Leakage resistance of the fuel system		Measurement accuracy and DFM Marine performance is not guaranteed in case of a leakage in the fuel system. Fuel system repair is recommended to eliminate leaks
Pressure of the fuel supply system		DFM Marine performance is not guaranteed in case of an insufficient pressure in the fuel system. Maintenance of the fuel pump is recommended.
Injectors return flow rate		Injectors return flow being higher than normal can significantly affect measurement accuracy. Injectors maintenance or replacement is recommended.
Onboard voltage		DFM Marine performance is not guaranteed in case of insufficient power supply voltage. Maintenance of the onboard power supply network and/or generator.
Chassis ground switch condition		DFM Marine performance is not guaranteed in case of significant resistance/oxidation of the switch. Maintenance or replacement is recommended.

representative of the CUSTOMER:

name, signature

representative of the CONTRACTOR:

name, signature

Annex C

Template of check test report

_____/_____/20_____
Date Month Year

Vehicle type, model, registration number	
DFM Marine model, serial number	

Fuel consumption	Actual fuel consumption. according to calibrated container V_m , liters	
	Fuel consumption measured According to DFM Marine reading V_{measured} , liters	
Relative error of fuel consumption measurement	$\delta = \frac{V_{\text{measured}} - V_m}{V_m} \cdot 100\%, \%$	

Resume:

Fuel consumption measurement **corresponds /does not correspond** to the technical specification.

Comments:

representative of the CUSTOMER:

representative of the CONTRACTOR:


name, signature

name, signature


Annex D

Signal cables

S6 SC-CW-700 Cable



Cable length 700±5 cm.




Pin	Wire color	Circuit
1	orange	VBAT
2	brown	GND
3	blue	CANH
4	white	CANL
5	black	KLIN
6	-	-


Connecting

without built-in terminal resistor R2

with built-in terminal resistor R2




* Do not connect R2 resistor wires (pink, identification mark R), insulate.




** Connect electrically one of the R2 resistor wires (pink, identification mark R) with CANH wire, and the other - with CANL wire.

CABLE DFM.98.20.003 Cable



Cable length 750±5 cm.



Pin	Wire color	Circuit
1	orange	VBAT
2	brown	GND
3	-	-
4	white	imp
5	-	-
6	-	-

Annex E

DFM Marine CAN connection options




Figure E.1 — Connection of single DFM Marine CAN to recording and display unit non-compatible with S6 cable system




Figure E.2 — Connection of several DFM Marine CAN to recording and display unit non-compatible with S6 cable system




Figure E.3 — Connection of single DFM Marine CAN to recording and display unit compatible with S6 cable system




Figure E.4 — Connection of several DFM Marine CAN to recording and display unit compatible with S6 cable system

Annex F

SPN of DFM Marine Functional modules

Hourly (instant) fuel consumption measurement, Counters, Events registration, Parameters configuration and self-diagnostics of DFM Marine is ensured by coordinated operation of its [Functional Modules](#) (FM).

[SPN](#) format of DFM Marine FM is in accordance with [Database](#) (DB) of [Telematics interface S6](#).

The following FM are included in DFM Marine fuel flow meters:

1) [Self-diagnostics FM](#) — designed for user authorization, identification of DFM Marine passport data, operation time recording and also active and saved malfunctions.

Table F.1 — Self-diagnostics FM. SPN. SPNs, displayed and/or editable in Service DFM Marine software

SPN	Name	Factory value	Unit of measure	Clarification
Unit passport PGN 62995				
521120	Serial number	On the fact	No	Serial number is a set of numbers that is used for identification of specific DFM Marine. Serial number DFM Marine has the following format: AABBB C DDDDD, where: AA – code of DFM Marine model; BBB – digits that reflect changes product changes; C – Manufacturer code; DDDDD – sequential number. Setting is not available for editing.
521345	Model	On the fact	No	Model – this is version of the sensor inside of DFM product line. Each model has its own functional and constructive features. Setting is not available for editing.
521123	Line	DFM Marine	No	Name of the product line. The line represents a group of similar products – fuel flow meters produced under general trademark DFM Marine . Setting is not available for editing.
521344	Brand	TECHNOTON	No	Name of DFM Marine Manufacturer. Setting is not available for editing.
521121	Firmware version	On the fact	No	Version of built in Software DFM Marine. Setting is not available for editing.
521125	Manufacturing date	On the fact	No	Date (day, month, year) of DFM Marine production. Setting is not available for editing.
521188	S6 address (SA)	111	No	Network DFM Marine address at Telematics interface S6 . Network address value can be selected by user in range: 111...118.
Unit work counters PGN 62994				
521116	Unit hours of operation	On the fact	s	Counter of summarized working time of the DFM Marine since its production moment. The user cannot reset the value of this counter. It can be reset by the Manufacturer or RSC only.

SPN	Name	Factory value	Unit of measure	Clarification
521118	Unit reset counter	On the fact	pc.	Counter of DFM Marine processor restarts at a time when the power is On or there is an impact of conducted interferences of the vehicle's on-board network. Restarts accounting is carried out since production date of the DFM Marine. The user cannot reset the value of this counter. It can be reset by the Manufacturer or RSC only.
Passwords PGN 63017				
521593 /3.3	Password/ 3.3 Installer	1111	No	Password is entered for user authorization while establishing connection session between fuel flow meter and service Software for configuring the DFM Marine. Password is a specific combination of four digits. By default, used: Login – 0, password – 1111. User can change password of the DFM Marine. After entering and confirming the new password is recorded into internal memory of the DFM Marine.
Active diagnostic trouble codes PGN 65226				
521044	Fault identifier (SID)	On the fact	No	List of current DFM Marine malfunctions are displayed at the settings field (in case of its presence — up to 10). For each active malfunction is indicated following: - faulty nod; - malfunction name. This setting allows to monitor DFM Marine working performance. In case of lack of active malfunctions, the following message is displayed "No malfunctions".
Previously active diagnostic trouble codes PGN 65227				
521044	Fault identifier (SID)	On the fact	No	List of saved DFM Marine malfunctions are displayed at the settings field (in case of its presence — up to 20). For each saved malfunction is indicated following: - faulty nod; - malfunction name; - malfunction counter. This setting allows to monitor DFM Marine working performance. In case of lack of saved malfunctions, the following message is displayed "No malfunctions".
Unit output interface PGN 63168				
521438	Interface Type Mask	On the fact	No	Shows type of connected unit's interface (CAN/RS232/RS485/pulse/voltage/frequency/current/GSM). Depending on interface type, service software loads Unit's Functional Modules configurations. Setting is not available for editing.

2) Onboard Clock FM — designed for generation of signals of time and its transmission to other functional modules DFM Marine.

Table F.2 — Onboard Clock FM. SPNs, displayed and/or editable in Service DFM Marine software

SPN	Name	Factory value	Unit of measure	Clarification	Clarification
Time/Date PGN 65254					
959	Seconds	On the fact	s	0...62.5	Present time — seconds. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
960	Minutes	On the fact	Min	0...250	Present time — minutes. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
961	Hours	On the fact	h	0...250	Present time — hours. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
963	Month	On the fact	month	0...250	Present date — month. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
962	Day	On the fact	d	0...62.5	Present date — day. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
964	Year	On the fact	year	1985...2235	Present date — year. Used during Events registration. Present time is available for user for editing manually or synchronizing of date/time with computer clock. By default, time is set in UTC format (Coordinated Universal Time standard) and displayed according to local displacement.
1601	Local minute offset	0	min	0...59 min	Time displacement (in minutes) in relation to Coordinated Universal Time that matches with local time (Time zone). It is activated and available for editing when configuring present time manually and when synchronizing time with PC.
1602	Local hour offset	+3	h	-24...+24 h	Time displacement (in hours) in relation to Coordinated Universal Time that matches with local time (Time zone). It is activated and available for editing when configuring present time manually and when synchronizing time with PC.
Time origin settings PGN 63011					
521350	Automatic daylight savings time and back	Off	No	On/Off	Daylight saving time automatic adjustment ON/OFF.

3) [Flowmeter Marine FM](#) — shows hourly (instant) fuel consumption, total fuel consumption and engine operation time – in total and in several operation modes.

Table F.3 — Flowmeter Marine FM. SPN, displayed and/or editable in Service DFM Marine software

SPN	Name	Factory value	Unit of measure	Clarification
Flowmeter. Parameters PGN 63159				
521313	Engine Fuel Rate	On the fact	m ³ /h	Hourly rate consumption of fuel, going through measuring chamber of DFM Marine.
521181	Engine Mode by Fuel Rate	On the fact	No	Current operation mode of fuel consumer, correspondent to hourly rate of fuel consumption.
Average fuel rate PGN 63162				
521313 /2.1	Engine Fuel Rate / 2.1 Mean	On the fact	m ³ /h	Value of instant (hourly) consumption of fuel, which goes through measuring chamber of flowmeter, averaged 30 s interval. This parameter provides possibility of handy instant fuel consumption monitoring when fuel consumer works unevenly.
Flowmeter. Counters PGN 63160				
521314	Total Fuel Used	On the fact	m ³	Overall fuel consumption of the Vehicle in all operation modes including "Idle". The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.0	Total Fuel Used/ 9.0 Idle	On the fact	m ³	Overall fuel consumption of the Vehicle in "Idle" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.1	Total Fuel Used/ 9.1 Optimal	On the fact	m ³	Overall fuel consumption of the Vehicle in "Optimal" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.2	Total Fuel Used/ 9.2 Overload	On the fact	m ³	Overall fuel consumption of the Vehicle in "Overload" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.3	Total Fuel Used/ 9.3 Cheat	On the fact	m ³	Overall fuel consumption, which was higher than configured highest boundary of fuel consumption rate for installed flow meter. Increasing numbers on the Counter can mean either possible fuel line intervention or incorrect installation of fuel flow meter. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /28.0	Total Fuel Used/ 28.0 Clearable	On the fact	m ³	Overall fuel consumption of the Vehicle in all operation modes including "Idle". Counter is growing since the moment of previous reset by User. This Counter is useful for precise fuel dosing.
521171	Engine Hours Of Operation	On the fact	s	Overall vehicle's engine operation time in various operation modes, including operation time in "Idle" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.0	Engine Hours Of Operation/9.0 Idle	On the fact	s	Overall vehicle's engine operation time in "Idle" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.1	Engine Hours Of Operation/9.1 Optimal	On the fact	s	Overall vehicle's engine operation time in "Optimal" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.2	Engine Hours Of Operation/9.2 Overload	On the fact	s	Overall vehicle's engine operation time in "Overload" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.

SPN	Name	Factory value	Unit of measure	Clarification
521171 /9.3	Engine Hours Of Operation/9.3 Cheat	On the fact	s	Overall vehicle's engine operation time when fuel consumption was higher than configured highest boundary of fuel consumption rate for installed flow meter. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /28.0	Engine Hours Of Operation/28.0 Clearable	On the fact	s	Overall vehicle's engine operation time in various operation modes, including operation time in "Idle" mode. Counter is growing since the moment of previous reset by user. This Counter is useful for precise fuel dosing.
521171 /9.5	Engine Hours Of Operation/9.5 Interference	On the fact	s	Overall time of external factors influence (e.g. magnetic field), which prevent normal functioning of DFM Marine. The Counter is increasing from the date of flow meter production and cannot be reset by user.
Flowmeter. Engine total hours of operation in interference mode PGN 63174				
521171 /9.5	Engine Hours Of Operation/9.5 Interference	On the fact	s	Overall time of external factors influence (e.g. magnetic field), which prevent normal functioning of DFM Marine. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521267	Interference sensor occurrence count	On the fact	pcs.	Counter for recording quantity of interference attempts (e.g. with magnetic field), which are aimed to stop flowmeter.
High Resolution Fuel Consumption (Liquid) PGN 63161				
521316	High Resolution Engine Trip Fuel	On the fact	m ³	Fuel consumption with higher accuracy, which is increasing since turning on ignition, and reset on turning off ignition. Counter is not available in current FW version.
521331	Total Engine Fuel Used. High Resolution	On the fact	m ³	Total fuel consumption with higher accuracy, which is increasing since the moment of flowmeter manufacture. Counter cannot be reset by User.
Borders. Fuel Rate PGN 63163				
521317 /9.0	Fuel Rate Mode Border/ 9.0 Idle	On the fact	m ³ /h	"Idle" operation mode boundary setting – less than 10 % of maximal hourly consumption rate of fuel, going through the measurement chamber of DFM Marine. The setting is used for defining current vehicle operation mode depending on hourly fuel consumption rate. The setting is available for editing by user.
521317 /9.1	Fuel Rate Mode Border/ 9.1 Optimal	On the fact	m ³ /h	"Optimal" operation mode boundary setting – 10 to 75 % of maximal hourly fuel consumption rate. The setting is used for defining current vehicle operation mode depending on hourly fuel consumption rate. The setting is available for editing by user.
521317 /9.2	Fuel Rate Mode Border/ 9.2 Overload	On the fact	m ³ /h	"Overload" operation mode boundary setting – 75 to 100 % of maximal hourly fuel consumption rate. The setting is used for defining current vehicle operation mode depending on hourly fuel consumption rate. Not available for editing by user.
Fuel Consumption Factors PGN 63026				
521311	Temperature correction enable	Off	On/Off	Function of automatic volumetric fuel consumption measurement correction depending on fuel temperature, which allows to increase accuracy of DFM Marine. A use can turn on/off the function.
521433	Temperature correction coefficient	0.084	%/°C	Setting-up coefficient of volumetric expansion of fuel depending on fuel temperature change may increase accuracy of measurements by DFM Marine. The setting can be adjusted by user only after turning on function of temperature correction (see 2.6.7)
521434	Correction coefficient	0.0	%	Setting-up correction coefficient of consumption may increase accuracy of fuel consumption measurement when constant over/undermeasurement during specific conditions of operation (high vibration, air in fuel lines, higher return flow from nozzles) is detected. The setting is available for editing by user (see 2.6.7)

SPN	Name	Factory value	Unit of measure	Clarification
Differential operation mode PGN 63204				
521268	Master Mode	Off	No	Enabling Master mode for primary flowmeter (fuel supply line) and disabling Master (return fuel line) from a pair, which is used in differential mode (see 2.6.8).
521270	Calculation Mode	Differential	No	Selecting necessary mode of flowmeter: Differential – fuel consumption is calculated as a difference between fuel consumption measured by flowmeter in supply and return lines. Summing – fuel consumption is calculated as a sum of fuel consumption measured by flowmeter in first and second fuel lines.
521269	Slave Device Address	112	No	Enter a unique network address for Slave-flowmeter (from 111...118 range). Elected address should not be the same as Master-flowmeter has.
521271	Differential Fuel Rate Correction Coefficient	0.0	No	Setting-up correction coefficient of consumption may increase accuracy of fuel consumption differential measurement when constant over/undermeasurement during specific conditions of operation (high vibration, air in fuel lines, higher return flow from nozzles) is detected. The setting is available for editing by user
Borders. Differential fuel rate PGN 63205				
521317 /9.0/2.15	Fuel Rate Mode Border/9.0 Idle/2.15 Differential	On the fact	m ³ /h	"Idle" operation mode boundary setting – less than 10 % of maximal hourly consumption rate of fuel (differential mode), going through measuring chambers of Master-flowmeter (fuel supply line) and Slave-flowmeter (fuel return lines). The setting is used for defining current vehicle operation mode depending on hourly fuel consumption rate. The setting is available for editing by user.
521317 /9.1/2.15	Fuel Rate Mode Border/9.1 Optimal/2.15 Differential	On the fact	m ³ /h	"Optimal" operation mode boundary setting – 10 to 75 % of maximal hourly fuel consumption rate (differential mode going through measuring chambers of Master-flowmeter (fuel supply line) and Slave-flowmeter (fuel return lines). The setting is used for defining current vehicle operation mode depending on hourly fuel consumption rate. The setting is available for editing by user.
521317 /9.2/2.15	Fuel Rate Mode Border/9.2 Overload/2.15 Differential	On the fact	m ³ /h	Overload" operation mode boundary setting – 75 to 100 % of maximal hourly fuel consumption rate (differential mode), going through measuring chambers of Master-flowmeter (fuel supply line) and Slave-flowmeter (fuel return lines). Not available for editing by user.
Differential fuel rate. Params PGN 63196				
521313 /2.15	Engine fuel rate/2.15 Differential	On the fact	m ³ /h	Differential hourly (instant) fuel consumption, going through measuring chambers of Master-flowmeter (fuel supply line) and Slave-flowmeter (fuel return lines).
521181 /2.15	Engine mode by fuel rate/2.15 Differential	On the fact	No	Current fuel consumer operation mode, corresponding to the value of differential hourly fuel consumption mode.
Differential fuel rate. Counters PGN 63197				
521314 /2.15	Total fuel used/2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of the Vehicle in all operation modes including "Idle". The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.0/2.15	Total fuel used/9.0 Idle /2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of the Vehicle in "Idle" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.1/2.15	Total fuel used/9.1 Optimal /2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of the Vehicle in "Optimal" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.

SPN	Name	Factory value	Unit of measure	Clarification
521314 /9.2/2.15	Total fuel used/ 9.2 Overload/ 2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of the Vehicle in "Overload" operation mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /9.3/2.15	Total fuel used/ 9.3 Cheat/ 2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode), which was higher than configured highest boundary of fuel consumption rate for installed flow meter. Increasing value of this Counter may point on improper installation of flow meter or possible events of fuel theft. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521314 /28.0/2.15	Total fuel used/ 28.0 Clearable/ 2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of the Vehicle in all operation modes including "Idle". Counter is growing since the moment of previous reset by user. This Counter is useful for precise fuel dosing.
521314 /9.4/2.15	Total fuel used/ 9.4 Negative/ 2.15 Differential	On the fact	m ³	Overall fuel consumption (differential mode) of Vehicle, when fuel consumption in reverse fuel line was higher than in direct fuel line. The Counter is incremented only in differential measurement. "Total "Negative" fuel consumption" Counter increasing numbers can mean increased volume of foam in reverse fuel line when Vehicle is operated at higher RPMs. The reason of foam volume growing is air presence in reverse fuel line cause by not tight hose connections or specifics of fuel system of Vehicle. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /2.15	Engine hours of operation/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) in various operation modes, including operation time in "Idle" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.0/2.15	Engine hours of operation/ 9.0 Idle/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) in "Idle" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.1/2.15	Engine hours of operation/ 9.1 Optimal/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) in "Optimal" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.2/2.15	Engine hours of operation/ 9.2 Overload/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) in "Overload" mode. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.3/2.15	Engine hours of operation/ 9.3 Cheat/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) when fuel consumption was higher than configured highest boundary of fuel consumption rate for installed flow meter. The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /28.0/2.15	Engine hours of operation/ 28.0 Clearable/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time (differential mode) in various operation modes, including operation time in "Idle" mode. Counter is growing since the moment of previous reset by user. This Counter is useful for precise fuel dosing.
521171 /9.5/2.15	Engine hours of operation/ 9.5 Interference/ 2.15 Differential	On the fact	s	Overall time of external factors influence (e.g. magnetic field), which prevent normal functioning of DFM Marine (differential mode). The Counter is increasing from the date of flow meter production and cannot be reset by user.
521171 /9.4/2.15	Engine hours of operation/ 9.4 Negative/ 2.15 Differential	On the fact	s	Overall vehicle's engine operation time when fuel consumption in reverse fuel line was higher than in direct fuel line (differential mode). Counter is increasing during differential measurement. Increasing value of negative consumption points on foaming in return line when engine is working on high RPM. Cause of foaming is air in return fuel line, which appears because of depressurization or special features of Vehicle's fuel system. The Counter is increasing from the date of flow meter production and cannot be reset by user.

SPN	Name	Factory value	Unit of measure	Clarification
Flowmeter characteristics PGN 63165				
521333	Flowmeter type	On the fact	No	Factory setting of flowmeter type: one-chamber or differential. Cannot be modified by user.
521230	Nominal chamber volume	On the fact	ml	Factory setting of measurement chamber nominal volume from range: 5, 12.5, 20, 30, 75, 150 ml. Cannot be modified by user.
Calibration Table. Fuel Rate (DFM) PGN 63044				
521355	Array elements count	10	pcs.	Quantity of points in calibration table made by Manufacturer during calibration process. The setting cannot be altered by user.
521232	Impulse period	On the fact	ms	The period of the output pulse signal (see 1.6.8) is set during the calibration of the flowmeter by the manufacturer.
521231	Chamber volume	On the fact	ml	Fuel flow meter's measurement chamber(s) volume (see. 1.6.3). The setting cannot be altered by user.

4) [Voltage supply monitoring FM](#) — designed for monitoring of onboard power voltage and ignition key status.

Table F.4 — Voltage supply monitoring FM. SPN, displayed and/or editable in Service DFM Marine software

SPN	Name	Factory value	Unit of measure	Range	Clarification
Vehicle voltage PGN 62987					
158	Key switch battery potential	On the fact	V	0...3212.75	Setting displays present onboard voltage of ignition key on the Vehicle .
521049	Ignition key state	On the fact	No	On/Off	Setting displays present status of ignition key of the vehicle (On/Off).
521053	Ignition on time	On the fact	s	0...4211080000	Counter of summarized time when the ignition key is On since the moment of DFM Marine installation on the vehicle. The user cannot reset the value of this counter. It can be reset by the Manufacturer or RSC only.
Battery voltage mode borders PGN 63064					
521391 /2.8	Battery voltage mode border/ 2.8 Min	10.0	V	8.0...15.0	Value of the lower level of onboard voltage range of DFM Marine. This setting is available for editing by user. Set value of the voltage is used as a threshold while registering an important Event "Low level of onboard power supply".
521391 /2.7	Battery voltage mode border/ 2.7 Max	30.0	V	15.0...32.0	Value of the upper level of onboard voltage range of DFM Marine. This setting is available for editing by user. Set value of the voltage is used as a threshold while registering an important Event "High level of onboard power supply".

5) Battery FM — designed for power supply status check, built-in battery condition and total DFM Marine operation time from the battery.

Table F.5 — Battery FM. SPN, displayed and/or editable in Service DFM Marine software

SPN	Name	Factory value	Unit of measure	Clarification
Battery PGN 63086				
521129	Unit power status	On the fact	No	Current power-supply status of DFM Marine: - powered from embedded power source; - powered from on-board electrical system; - power is off; - power-supply status is not available/not supported by this device. While working with service software, data exchange between PC and fuel flow meter is possible only if flow meter is power-supplied from external source and power-supply status of DFM Marine will always be displayed as "powered from on-board electrical system".
167	Charging system potential (voltage)	On the fact	V	Current voltage of embedded battery of DFM Marine. When working with service software, this setting will always be displayed as "not available/not supported by this device".
521061	Battery charge level	On the fact	%	Current charge of embedded battery of DFM Marine. When working with service software, this setting will always be displayed as "not available/not supported by this device".
521116 /16.1	Unit hours of operation/ 16.1 Battery	On the fact	s	Counter of total operation time of DFM Marine from embedded battery since installation to Vehicle. The Counter cannot be reset by user. Reset is possible in Regional Service Centers.

Detailed parameters description ([SPN](#)), structure and content of messages ([PGN](#)) of FM DFM Marine are placed at the following web site <http://s6.jv-technoton.com/en> (to access S6 DB registration is required)

Annex G

DFM Marine firmware upgrade




ATTENTION: [DFM Marine](#) firmware update should be done **only** for implementation of improvements, recommended by [Manufacturer](#).

To upgrade DFM Marine firmware the following actions should be made:


1) Connect sensor to PC with the help of service adapter and establish connection session between DFM Marine and PC (see [2.6.3](#)).




ATTENTION: When re-uploading firmware, power supply voltage of DFM Marine should not drop out of 10...45 V range.

2) Press  button at Service DFM Marine Software.

3) Choose firmware upgrade file (***.blf3**) on PC or memory stick.

4) Press  button, that will start firmware file downloading into DFM Marine memory.

After firmware file integrity and compatibility check by Service DFM Marine Software window of firmware uploading into DFM Marine memory will appear. In case of any errors the Software will send warning message.

To cancel firmware upgrade it is needed to press  button.



ATTENTION: Before the end of the update process and automatic Service DFM Marine Software reset it is **forbidden**

- 1)** Disconnect DFM Marine from the adapter.
- 2)** Disconnect adapter from the PC.
- 3)** Power down the PC.
- 4)** Run any resource-intensive applications on the PC.


Service DFM Marine Software will display appropriate message and automatically will disconnect DFM Marine from PC in case the update is successful. DFM is ready for further operation.

Service DFM Marine Software will display a new firmware version with the next connection session between PC and DFM Marine.


In case of any error occur that led to the damage of present DFM Marine firmware check all cables and adapter connections and retry. In this case the internal firmware loader is activated and will try to fix DFM Marine operation performance. Contact [Technoton technical support](#) at support@technoton.by if another try is also unsuccessful.

Annex H

DFM Marine mounting plate drawing



a) for DFM Marine 1000/2000 installation



b) for DFM Marine 4000 installation

Figure H.1 — Mounting plate

Annex I

Videos

1) DFM Fuel Flow Meter Installation video (DFM installation on MTZ tractor. After pump (pressure side) scheme).

Link:  <https://www.youtube.com/watch?v=ATscYhBsD3c>

2) DFM fuel flow meter operation principle video (fuel flow measurement principle of DFM measuring chamber).

Link:  <https://www.youtube.com/watch?v=RXjvwyy1zIY>

3) Interactive flash animation DFM fuel flow meter features



Link: http://www.jv-technoton.com/data/editor/dfm_fuel_flow_meter.swf

4) Interactive flash animation DFM fuel flow meter: selection of mounting scheme, accessories and mounting kit



Link: http://www.jv-technoton.com/data/editor/flash/DFM_choose_an_installation_scheme.swf

5) Check out YouTube channel for other Technoton videos at:

 <https://www.youtube.com/channel/UCq7EF3DHrgl7fOWB2ynsR-A>